DMX REFERENCE

Inno Pocket Spot

ADJ



Manufacturer	ADJ
GDTF file	ADJ_Inno_Pocket_Spot_98808.gdtf
GDTF revision	25-03-06 Release · 2025-06-03
Generated	2026-11-23

Contents

1 About this manual 2
2 Quick reference 3
3 Safety instructions 4
4 Product description 5
5 Installation 6
6 Connections 6
7 Operation 7
8 Functions at a glance 7
9 DMX channels 9
Mode 11CH 9
Mode 9CH 12
10 Technical specifications 13
11 Maintenance and cleaning 13
12 Troubleshooting 14
13 Disposal 14

1 About this manual

This document describes the Inno Pocket Spot by ADJ. It was compiled from the GDTF file ADJ_Inno_Pocket_Spot_98808.gdtf from the GDTF-Share library.

File revision: “25-03-06 Release”.

The DMX modes, the channel functions and the technical data are given as the GDTF file states them. Installation, operation from the device's control panel, service and safety instructions are described in the manufacturer's original user manual, which takes precedence over this document.

This document was not issued or endorsed by ADJ; product names and trademarks belong to their owners.

Safety notices are marked with signal words according to the severity of the hazard: DANGER – an imminent hazard that will result in death or serious injury; WARNING – a potential hazard that could result in death or serious injury; CAUTION – a potential hazard that could result in minor injury or property damage; NOTE – additional information for correct and safe use.

> **NOTE** This product is designed for stage and effect lighting. It is not suitable for household room illumination.

2 Quick reference

Parameter	Value
Weight	7.5 kg

DMX modes

Mode	Channels	Units in one universe	First start addresses
11CH	11	46	1, 12, 23, 34, ...
9CH	9	56	1, 10, 19, 28, ...

No light? Check these channels

- 11CH: CH 7 Shutter at 8–15, 132–139, 182–189, 232–239 or 248–255
- 9CH: CH 5 Shutter at 8–15, 132–139, 182–189, 232–239 or 248–255


Read the manual before use


Do not stare into the light


Indoor use only

3 Safety instructions



Read the manual before use



Do not stare into the light



Indoor use only

⚠ WARNING

- This device is intended for professional use. Installation, connection, setup and maintenance must be carried out only by suitably qualified persons who have read this manual.
- Use the device only for its intended purpose and as described in this manual.
- Do not open the housing and do not modify or tamper with the device. Refer all repairs to an authorized service center.
- Do not use the device if its housing, power or data cable, or a connector is damaged, if the device has been dropped, or if liquid or a foreign object has entered it. In such a case, have it checked by a service center.
- Disconnect the device from the power supply before cleaning, maintenance or any work on the connections.
- After moving the device from a cold to a warm environment, let it reach room temperature before switching it on to prevent condensation inside.
- The device is not a toy; keep it out of the reach of children.

⚠ WARNING

- This device is designed for indoor use only. Protect it from rain, splashing water, moisture and dust, and do not place containers with liquids on it.
- Do not operate the device in high humidity, near water, or where condensation can form on it.

⚠ CAUTION

- This device emits intense light. Do not look directly into the light source or the beam at close range; doing so may damage your eyes.
- Do not aim the beam at the eyes of people or animals at close range, and do not view the light source through optical instruments (binoculars, camera lenses).
- Do not aim the beam at flammable or heat-sensitive materials at close range.

⚠ CAUTION

- Strobe and fast flashing light effects can trigger epileptic seizures in susceptible people (photosensitive epilepsy) and can cause nausea or disorientation.
- Inform the audience and performers in advance that strobe effects will be used, for example with a notice at the entrance, and do not use them longer than necessary.

> ⚠ **WARNING**
>
> - The moving parts of the device (for example the head or arms) can move quickly and unexpectedly at any time – after power-on, during a reset, or on a command from the controller.
> - Keep yourself and any objects out of the range of movement. While the device is switched on, do not touch the moving parts, move them by hand, or obstruct their movement; this can cause injury (pinching) and damage the drive.
> - Do not carry the device by its moving parts. If the device has a transport lock, engage it before transport and release it before switching on.

4 Product description

Description in the GDTF file

“The perfect addition to any small venues such as nightclubs, bars, stages, churches or mobile performers, the Inno Pocket Spot give a professional Moving Head light show. This compact mover is powered by a bright 12W LED engine. A "you have to see it to believe it" brightness! Compatible with the ADJ Airstream IR App.”

Range of movement



Full-travel times as stated in the GDTF file.

5 Installation

⚠ WARNING

- Rigging must be carried out only by qualified persons in accordance with applicable regulations, in particular those for work at height.
- The supporting structure and fixings must safely carry the weight of all suspended devices; verify their load capacity in advance.
- Weight of the device: 7.5 kg.
- Use suitable mounting hardware (for example truss clamps) and tighten all screw connections properly.
- Always secure the suspended device against falling with a safety cable of adequate load capacity, routed through a fixed point of the device and around the supporting structure.
- During installation and removal, keep people out of the area below the work position.
- Regularly inspect the fixings and the safety cable for damage, corrosion and loosening.

6 Connections

- Use shielded cable designed for DMX512 with an impedance of 110 Ω. Ordinary microphone cable is not suitable for DMX, especially over longer distances.
- Connect the devices in a daisy chain: connect the DMX OUT of one device to the DMX IN of the next. Do not split the line with Y-cables or wire it in a star; the line may be split only with a DMX splitter.
- Connect the shield to pin 1 only. Do not connect the shield (ground) to the metal shell of the connector; this can cause short circuits or erratic behavior.
- XLR pin assignment: pin 1 – shield (ground), pin 2 – Data- (Data Complement), pin 3 – Data+ (Data True). On 5-pin connectors, pins 4 and 5 are not connected; a 5-pin connector can be connected to a 3-pin one with a cable adapter.
- Terminate the end of the line (for impedance matching): plug an XLR connector with a 120 Ω, ¼ W resistor between pins 2 and 3 into the DMX OUT of the last device. This reduces the risk of erratic behavior.
- Connect no more than 32 devices to one DMX line. For more devices or longer runs, use a DMX splitter or booster.

DMX line



Mode 11CH: every unit occupies 11 channels from its address. At most 32 units on one line; for more units or longer runs use a DMX splitter. A 120 Ω terminator closes the last DMX OUT.

7 Operation

Setting the DMX address

- The device occupies as many consecutive channels in the DMX universe as the selected DMX mode uses, starting at the set start address.
- Number of channels occupied in the DMX mode “11CH”: 11.
- Choose start addresses so that the channels of individual devices do not overlap and the last occupied channel does not exceed 512. Devices with the same start address and mode respond identically.
- For several devices in a row in the DMX mode “11CH”, you can use, for example, the start addresses 1, 12, 23, 34.
- The DMX mode set on the device must match the fixture profile (personality) used in the controller.

8 Functions at a glance

Functions in each DMX mode

	11CH 11 channels	9CH 9 channels
Pan / Tilt	1, 3	1, 2
Pan / Tilt resolution	16 bit	8 bit
Dimmer	8	6
Shutter / strobe	7	5
Color wheel	5	3
Gobo wheel	6	4

Color wheel

1 WHITE DMX 0–7

2 RED DMX 8–14

3 ORANGE DMX 15–21

4 YELLOW DMX 22–28

5 GREEN DMX 29–35

6 BLUE DMX 36–42

7 LIGHT BLUE DMX 43–49

8 PINK DMX 50–56

Gobo wheel

1	Gobo: Open	DMX 0–7	4 Gobo 3	DMX 24–31	7 Gobo 6	DMX 48–55
2	Gobo 1	DMX 8–15	5 Gobo 4	DMX 32–39	8 Gobo 7	DMX 56–64
3	Gobo 2	DMX 16–23	6 Gobo 5	DMX 40–47		

Strobe rate



CH 7 · 11CH

190–231: 5–1 Hz
SHUTTER FAST OPEN - SLOW CLOSE

9 DMX channels

Units in one DMX universe



Start addresses of 20 units in the mode “11CH”

Unit	Start address	Unit	Start address	Unit	Start address	Unit	Start address
1	1	6	56	11	111	16	166
2	12	7	67	12	122	17	177
3	23	8	78	13	133	18	188
4	34	9	89	14	144	19	199
5	45	10	100	15	155	20	210

Mode 11CH

16-bit parameters use two channels, coarse and fine: value = 256 × coarse value + fine value.

If the device receives DMX in this mode but gives no light, check these channels: CH 7 Shutter at 8–15, 132–139, 182–189, 232–239 or 248–255. The GDTF file gives these values for a console's Highlight function: CH 7 Shutter 255, CH 8 Dimmer 255.

Channel functions at a glance



CH	Function	DMX	Description
1	Pan	0–128	Min ... Center
		128–255	Center ... Max
		255	Max
2	Pan Fine	0–255	Fine adjustment of CH 1
3	Tilt	0–127	Min ... Center
		127	Center

CH	Function	DMX	Description
3	Tilt (continued)	128–255	Center … Max
		255	Max
4	Tilt Fine	0–255	Fine adjustment of CH 3
5	Colors	0–7	WHITE
		8–14	RED
		15–21	ORANGE
		22–28	YELLOW
		29–35	GREEN
		36–42	BLUE
		43–49	LIGHT BLUE
		50–56	PINK
		57–127	Split
		128–189	Scroll Fast to Slow (360–10 °/s)
		190–193	Color Scroll: Stop
		194–255	Scroll Slow to Fast (10–360 °/s)
6	Gobo	0–7	Gobo: Open
		8–15	Gobo 1
		16–23	Gobo 2
		24–31	Gobo 3
		32–39	Gobo 4
		40–47	Gobo 5
		48–55	Gobo 6
		56–63	Gobo 7
		64–71	Gobo Shake: Open (1–5 Hz)
		72–79	Gobo Shake: Gobo 1 (1–5 Hz)
		80–87	Gobo Shake: Gobo 2 (1–5 Hz)
		88–95	Gobo Shake: Gobo 3 (1–5 Hz)
		96–103	Gobo Shake: Gobo 4 (1–5 Hz)
		104–111	Gobo Shake: Gobo 5 (1–5 Hz)
		112–119	Gobo Shake: Gobo 6 (1–5 Hz)
		120–127	Gobo Shake: Gobo 7 (1–5 Hz)
		128–189	SCROLL FAST - SLOW (360–10 °/s)
		190–193	Gobo Spin: STOP
		194–255	SCROLL SLOW - FAST (10–360 °/s)
7	Shutter	0–7	LED OFF
		8–15	Shutter Open/Close: LED ON
		16–131	STROBING SLOW - FAST (1–5 Hz)
		132–139	LED ON
		140–181	SHUTTER SLOW OPEN - FAST CLOSE
		182–189	LED ON
		190–231	SHUTTER FAST OPEN - SLOW CLOSE (5–1 Hz)
		232–239	LED ON

CH	Function	DMX	Description
7	Shutter (continued)	240–247	RANDOM STROBE (1–5 Hz)
		248–255	LED ON
8	Dimmer	0	0 %
		1–62	0 % … 25 %
		63	25 %
		64–126	25 % … 50 %
		127	50 %
		128–190	50 % … 75 %
		191	75 %
		192–254	75 % … 100 %
		255	100 %
9	Speed Pan/Tilt		Pan/Tilt Fast to Slow
		0–255	Fast to Slow
10	Function		Special Function
		0–69	NO FUNCTION
		70–79	BLACKOUT WITH PAN/TILT
		80–89	NO BLACKOUT WITH PAN/TILT
		90–99	BLACKOUT WITH COLOR CHANGE
		100–109	NO BLACKOUT WITH COLOR CHANGE
		110–119	BLACKOUT WITH GOBO CHANGE
		120–129	NO BLACKOUT WITH GOBO CHANGE
		130–199	NO FUNCTION
		200–209	RESET ALL
		210–249	NO FUNCTION
		250–255	SOUND ACTIVE MODE
11	Dimmer Mode	0–20	STANDARD
		21–40	STAGE
		41–60	TV
		61–80	ARCHITECTURAL
		81–100	THEATER
		101–255	DEFAULT TO UNIT CURVE SETTING

Mode 9CH

If the device receives DMX in this mode but gives no light, check these channels: CH 5 Shutter at 8–15, 132–139, 182–189, 232–239 or 248–255. The GDTF file gives these values for a console's Highlight function: CH 5 Shutter 255, CH 6 Dimmer 255.

Channel functions at a glance



CH	Function	DMX	Description
1	Pan	0	Min
		1–127	Min ... Center
		128	Center
		129–254	Center ... Max
		255	Max
2	Tilt	0	Min
		1–126	Min ... Center
		127	Center
		128–254	Center ... Max
		255	Max
3	Colors		Same as CH 5 in the mode “11CH” (p. 10)
4	Gobo		Same as CH 6 in the mode “11CH” (p. 10)
5	Shutter		Same as CH 7 in the mode “11CH” (p. 10)
6	Dimmer		Same as CH 8 in the mode “11CH” (p. 11)
7	Speed Pan/Tilt		Same as CH 9 in the mode “11CH” (p. 11)
8	Function		Same as CH 10 in the mode “11CH” (p. 11)
9	Dimmer Mode		Same as CH 11 in the mode “11CH” (p. 11)

10 Technical specifications

Parameter	Value
Light	
Light source	LED
LED power	12 W
Luminous flux	1,000 lm
Color temperature	7,045 K
Color rendering index (CRI)	80
Optics	
Beam angle	13°
Movement	
Pan	525°
Tilt	180°
Dimensions and construction	
Weight	7.5 kg
Operating environment	
Operating temperature	0 to 40 °C

Speeds and ranges

Parameter	Value
Color wheel rotation	up to 360 °/s (60 rpm)
Gobo wheel rotation	up to 360 °/s (60 rpm)

Spot diameter



Distance	Ø 13°
2 m	0.46 m
4 m	0.91 m
6 m	1.4 m
8 m	1.8 m
10 m	2.3 m
15 m	3.4 m

Spot diameter square to the beam axis, calculated from the beam angle.

11 Maintenance and cleaning

- Before cleaning and maintenance, switch the device off, disconnect it from the power supply and let it cool down.
- Clean the housing with a soft, dry or slightly damp cloth. Do not use solvents, abrasive cleaners or pressure washers, and make sure no liquid gets into the device.
- Clean optical parts (lenses, front glass), if the device has any, with a soft lint-free cloth and a cleaner

intended for optics or glass.

- Regularly inspect the housing, cables, connectors and fixings. Have damaged parts replaced by a service center.
- How often to clean depends on the environment; dust, smoke and fog make the device dirty much faster.

12 Troubleshooting

Problem	Remedy
The device does not switch on	Check the supply voltage, the cables and the fuse, if the device has one.
The device does not respond to DMX	Check the start address, the selected DMX mode and whether it matches the profile in the controller, the cable connection to DMX IN, and the controller output (universe).
The device behaves erratically or flickers	Check the terminator at the end of the line, the condition and wiring of the cables (shield on pin 1 only), the number of devices on the line (32 at most), and that the line is not split without a splitter.
Only some devices on the line respond	Check the cable and connectors between the last working and the first non-working device, and make sure all devices on the line are switched on.
Devices respond to the wrong channels or affect each other	Check that the addresses do not overlap and that the DMX mode on the devices matches the patch in the controller.
The device or the connected load does not light up although it receives DMX	Check the values of the dimmer, shutter and strobe channels against the DMX channel table. For the DMX modes for which the sources state it, the chapter DMX channels gives under the mode's heading which channels must be open.
Movement is reversed	Check whether Pan/Tilt inversion is enabled in the device menu or in the controller.
Moving parts do not reach the correct position after power-on or transport	Switch the device off and on again to reset the position, and make sure the transport lock, if any, is released. If this does not help, contact a service center.
Movement is jerky	Check the value of the Pan/Tilt speed channel, if the device has one, and the stability of the DMX signal.

13 Disposal

The crossed-out wheeled bin symbol on the product, in the manual or on the packaging means that the product must not be disposed of with unsorted household waste at the end of its life.

Take the end-of-life equipment to a collection point, for example a municipal collection site or a retailer. Proper disposal enables materials to be recycled and helps prevent possible negative effects on the environment and human health.

Follow the regulations applicable in your country; in the Czech Republic, take-back is governed by Act No. 542/2020 Coll., on End-of-Life Products.

Recycle the packaging materials according to their type.