DMX REFERENCE

KingWash 19QX

Artfox



Manufacturer	Artfox
GDTF file	Artfox_KingWash_19QX_107228.gdtf
GDTF revision	Final-GDTF-11082025_1654 · 2025-08-11
Generated	2026-11-23

Contents

1 About this manual 2
2 Quick reference 3
3 Safety instructions 4
4 Product description 5
5 Installation 5
6 Connections 5
7 Operation 6
8 Functions at a glance 7
9 DMX channels 9
Mode Rings 27 CH 10
Mode Standard 19CH 13
10 Technical specifications 14
11 Maintenance and cleaning 14
12 Troubleshooting 15
13 Disposal 15

1 About this manual

This document describes the KingWash 19QX by Artfox. It was compiled from the GDTF file Artfox_KingWash_19QX_107228.gdtf from the GDTF-Share library.

File revision: “Final-GDTF-11082025_1654”.

The DMX modes, the channel functions and the technical data are given as the GDTF file states them. Installation, operation from the device's control panel, service and safety instructions are described in the manufacturer's original user manual, which takes precedence over this document.

This document was not issued or endorsed by Artfox; product names and trademarks belong to their owners.

Safety notices are marked with signal words according to the severity of the hazard: DANGER – an imminent hazard that will result in death or serious injury; WARNING – a potential hazard that could result in death or serious injury; CAUTION – a potential hazard that could result in minor injury or property damage; NOTE – additional information for correct and safe use.

> **NOTE** This product is designed for stage and effect lighting. It is not suitable for household room illumination.

2 Quick reference

Parameter	Value
Weight	23 kg

DMX modes

Mode	Channels	Units in one universe	First start addresses
Rings 27 CH	27	18	1, 28, 55, 82, ...
Standard 19CH	19	26	1, 20, 39, 58, ...

No light? Check these channels

- Rings 27 CH: CH 6 Shutter at 0–15
- Standard 19CH: CH 6 Shutter at 0–15


Read the manual before use


Do not stare into the light


Indoor use only

3 Safety instructions



Read the manual before use



Do not stare into the light



Indoor use only

⚠ WARNING

- This device is intended for professional use. Installation, connection, setup and maintenance must be carried out only by suitably qualified persons who have read this manual.
- Use the device only for its intended purpose and as described in this manual.
- Do not open the housing and do not modify or tamper with the device. Refer all repairs to an authorized service center.
- Do not use the device if its housing, power or data cable, or a connector is damaged, if the device has been dropped, or if liquid or a foreign object has entered it. In such a case, have it checked by a service center.
- Disconnect the device from the power supply before cleaning, maintenance or any work on the connections.
- After moving the device from a cold to a warm environment, let it reach room temperature before switching it on to prevent condensation inside.
- The device is not a toy; keep it out of the reach of children.

⚠ WARNING

- This device is designed for indoor use only. Protect it from rain, splashing water, moisture and dust, and do not place containers with liquids on it.
- Do not operate the device in high humidity, near water, or where condensation can form on it.

⚠ CAUTION

- This device emits intense light. Do not look directly into the light source or the beam at close range; doing so may damage your eyes.
- Do not aim the beam at the eyes of people or animals at close range, and do not view the light source through optical instruments (binoculars, camera lenses).
- Do not aim the beam at flammable or heat-sensitive materials at close range.

⚠ CAUTION

- Strobe and fast flashing light effects can trigger epileptic seizures in susceptible people (photosensitive epilepsy) and can cause nausea or disorientation.
- Inform the audience and performers in advance that strobe effects will be used, for example with a notice at the entrance, and do not use them longer than necessary.

> ⚠ **WARNING**
>
> - The moving parts of the device (for example the head or arms) can move quickly and unexpectedly at any time – after power-on, during a reset, or on a command from the controller.
> - Keep yourself and any objects out of the range of movement. While the device is switched on, do not touch the moving parts, move them by hand, or obstruct their movement; this can cause injury (pinching) and damage the drive.
> - Do not carry the device by its moving parts. If the device has a transport lock, engage it before transport and release it before switching on.

4 Product description

Range of movement



5 Installation

> ⚠ **WARNING**
>
> - Rigging must be carried out only by qualified persons in accordance with applicable regulations, in particular those for work at height.
> - The supporting structure and fixings must safely carry the weight of all suspended devices; verify their load capacity in advance.
> - Weight of the device: 23 kg.
> - Use suitable mounting hardware (for example truss clamps) and tighten all screw connections properly.
> - Always secure the suspended device against falling with a safety cable of adequate load capacity, routed through a fixed point of the device and around the supporting structure.
> - During installation and removal, keep people out of the area below the work position.
> - Regularly inspect the fixings and the safety cable for damage, corrosion and loosening.

6 Connections

- Use shielded cable designed for DMX512 with an impedance of 110 Ω. Ordinary microphone cable is not suitable for DMX, especially over longer distances.

- Connect the devices in a daisy chain: connect the DMX OUT of one device to the DMX IN of the next. Do not split the line with Y-cables or wire it in a star; the line may be split only with a DMX splitter.
- Connect the shield to pin 1 only. Do not connect the shield (ground) to the metal shell of the connector; this can cause short circuits or erratic behavior.
- XLR pin assignment: pin 1 – shield (ground), pin 2 – Data- (Data Complement), pin 3 – Data+ (Data True). On 5-pin connectors, pins 4 and 5 are not connected; a 5-pin connector can be connected to a 3-pin one with a cable adapter.
- Terminate the end of the line (for impedance matching): plug an XLR connector with a 120 Ω, ¼ W resistor between pins 2 and 3 into the DMX OUT of the last device. This reduces the risk of erratic behavior.
- Connect no more than 32 devices to one DMX line. For more devices or longer runs, use a DMX splitter or booster.

DMX line



Mode Rings 27 CH: every unit occupies 27 channels from its address. At most 32 units on one line; for more units or longer runs use a DMX splitter. A 120 Ω terminator closes the last DMX OUT.

7 Operation

Setting the DMX address

- The device occupies as many consecutive channels in the DMX universe as the selected DMX mode uses, starting at the set start address.
- Number of channels occupied in the DMX mode “Rings 27 CH”: 27.
- Choose start addresses so that the channels of individual devices do not overlap and the last occupied channel does not exceed 512. Devices with the same start address and mode respond identically.
- For several devices in a row in the DMX mode “Rings 27 CH”, you can use, for example, the start addresses 1, 28, 55, 82.
- The DMX mode set on the device must match the fixture profile (personality) used in the controller.

8 Functions at a glance

Functions in each DMX mode

	Rings 27 CH 27 channels	Standard 19CH 19 channels
Pan / Tilt	1, 3	1, 3
Dimmer	7	7
Shutter / strobe	6	6
Color mixing	10–21	10–13
Color wheel	22	14
Zoom	9	9
Effects / macros	24–26	16–18
Pixel control	✓	

Color wheel

1. Open — DMX 0–16
2. Red — DMX 17–24
3. Green — DMX 25–32
4. Blue — DMX 33–40
5. Cyan — DMX 41–48
6. Yellow — DMX 49–56
7. Magenta — DMX 57–64
8. Medium Yellow — DMX 65–72
9. Straw Tint — DMX 73–80
10. Sunrise Peach — DMX 81–88
11. Fire — DMX 89–96
12. Medium Amber — DMX 97–104
13. Gold Amber — DMX 105–112
14. Dark Amber — DMX 113–120
15. Sunrise Red — DMX 121–128
16. Light Pink — DMX 129–136
17. Medium Pink — DMX 137–144
18. Pink Carnation — DMX 145–152
19. Light Lavender — DMX 153–160
20. Sky Blue — DMX 161–168
21. Blue Hue — DMX 169–176
22. Dark Yellow Green — DMX 177–184
23. Spring Yellow — DMX 185–192
24. Light Amber — DMX 193–200

25 Deep Amber
DMX 201–208

26 Orange
DMX 209–216

27 Light Rose
DMX 217–224

28 Medium Rose
DMX 225–232

29 Dark Pink
DMX 233–240

30 Magenta 2
DMX 241–249

31 Pure White
DMX 250–255

Strobe rate



Cells (pixels)



19 cells where the GDTF file places them (seen from above), numbered in the file's order; the mode “Rings 27 CH” drives them together.

9 DMX channels

Units in one DMX universe



Start addresses of 20 units in the mode “Rings 27 CH”

Unit	Start address	Unit	Start address	Unit	Start address	Unit	Start address
1	1	6	136	11	271	16	406
2	28	7	163	12	298	17	433
3	55	8	190	13	325	18	460
4	82	9	217	14	352	19	U2 · 1
5	109	10	244	15	379	20	U2 · 28

Where a DMX universe is full, the next units continue in the next universe: “U2 · 1” is address 1 in the second universe, counted from the universe of the first unit.

Mode Rings 27 CH

16-bit parameters use two channels, coarse and fine: value = 256 × coarse value + fine value.

If the device receives DMX in this mode but gives no light, check these channels: CH 6 Shutter at 0–15. The GDTF file gives these values for a console's Highlight function: CH 6 Shutter 0, CH 7 Dimmer 255, CH 10 Red 1 255, CH 11 Green 1 255, CH 12 Blue 1 255, CH 13 White 1 255, CH 14 Red 2 255, CH 15 Green 2 255, CH 16 Blue 2 255, CH 17 White 2 255, CH 18 Red 3 255, CH 19 Green 3 255, CH 20 Blue 3 255, CH 21 White 3 255, CH 22 Colors 0.

Channel functions at a glance



CH	Function	DMX	Description
1	Pan	0–127	PAN
		127	Center
		128–255	PAN
2	Pan Fine	0–255	Fine adjustment of CH 1
3	Tilt	0–127	TILT
		127	Center
		128–255	TILT
4	Tilt Fine	0–255	Fine adjustment of CH 3

CH	Function	DMX	Description
5	Speed Pan/Tilt		P/T SPEED
		0	Max
		1–254	Max … Min
		255	Min
6	Shutter	0–15	Open - Shutter Open
		16–214	Sync Strobe S > F - Strobe (0.1–10 Hz)
		215–255	Strobe Random S > F - Strobe Random (0.1–10 Hz)
7	Dimmer	0	Min
		1–254	Min … Max
		255	Max
8	Dimmer Curve	0–49	Mode 1
		50–99	Mode 2
		100–149	Mode 3
		150–255	Mode 4
9	Zoom	0	Narrow
		1–127	Narrow … Mid
		128	Mid
		129–254	Mid … Wide
		255	Wide
10	Red 1	0–255	
11	Green 1	0–255	
12	Blue 1	0–255	
13	White 1	0–255	
14	Red 2	0–255	
15	Green 2	0–255	
16	Blue 2	0–255	
17	White 2	0–255	
18	Red 3	0–255	
19	Green 3	0–255	
20	Blue 3	0–255	
21	White 3	0–255	
22	Colors	0–16	Open
		17–24	Red
		25–32	Green
		33–40	Blue
		41–48	Cyan
		49–56	Yellow
		57–64	Magenta
		65–72	Medium Yellow
		73–80	Straw Tint
		81–88	Sunrise Peach
		89–96	Fire

CH	Function	DMX	Description
22	Colors (continued)	97–104	Medium Amber
		105–112	Gold Amber
		113–120	Dark Amber
		121–128	Sunrise Red
		129–136	Light Pink
		137–144	Medium Pink
		145–152	Pink Carnation
		153–160	Light Lavender
		161–168	Sky Blue
		169–176	Blue Hue
		177–184	Dark Yellow Green
		185–192	Spring Yellow
		193–200	Light Amber
		201–208	Deep Amber
		209–216	Orange
		217–224	Light Rose
		225–232	Medium Rose
		233–240	Dark Pink
		241–249	Magenta 2
		250–255	Pure White
23	Color Mix Mode	0–49	OFF
		50–99	Skip Change
		100–255	Gradual Change
24	Effects	0–19	Pattern 1
		20–39	Pattern 2
		40–59	Pattern 3
		60–79	Pattern 4
		80–99	Pattern 5
		100–119	Pattern 6
		120–139	Pattern 7
		140–159	Pattern 8
		160–179	Pattern 9
		180–199	Pattern 10
		200–219	Pattern 11
		220–255	Pattern 12
25	Effects Speed	0–255	Effects 1 Speed (0–10 Hz)
26	Effects Fade	0–255	
27	Reset	0–79	OFF
		80–99	Fixture Global Reset
		100–255	OFF

Mode Standard 19CH

16-bit parameters use two channels, coarse and fine: value = 256 × coarse value + fine value.

If the device receives DMX in this mode but gives no light, check these channels: CH 6 Shutter at 0–15. The GDTF file gives these values for a console's Highlight function: CH 6 Shutter 0, CH 7 Dimmer 255, CH 10 Red 255, CH 11 Green 255, CH 12 Blue 255, CH 13 White 255, CH 14 Colors 0.

Channel functions at a glance



CH	Function	DMX	Description
1	Pan		Same as CH 1 in the mode “Rings 27 CH” (p. 10)
2	Pan Fine	0–255	Fine adjustment of CH 1
3	Tilt		Same as CH 3 in the mode “Rings 27 CH” (p. 10)
4	Tilt Fine	0–255	Fine adjustment of CH 3
5	Speed Pan/Tilt		Same as CH 5 in the mode “Rings 27 CH” (p. 11)
6	Shutter		Same as CH 6 in the mode “Rings 27 CH” (p. 11)
7	Dimmer		Same as CH 7 in the mode “Rings 27 CH” (p. 11)
8	Dimmer Curve		Same as CH 8 in the mode “Rings 27 CH” (p. 11)
9	Zoom		Same as CH 9 in the mode “Rings 27 CH” (p. 11)
10	Red	0–255	
11	Green	0–255	
12	Blue	0–255	
13	White	0–255	
14	Colors		Same as CH 22 in the mode “Rings 27 CH” (p. 11)
15	Color Mix Mode		Same as CH 23 in the mode “Rings 27 CH” (p. 12)
16	Effects		Same as CH 24 in the mode “Rings 27 CH” (p. 12)

CH	Function	DMX	Description
17	Effects Speed	0–255	Effects 1 Speed (0–10 Hz)
18	Effects Fade	0–255	
19	Reset		Same as CH 27 in the mode “Rings 27 CH” (p. 12)

10 Technical specifications

Parameter	Value
Light source	LED
Zoom	5–60°
Pan	540°
Tilt	270°
Weight	23 kg
Operating temperature	-20 to 45 °C

Speeds and ranges

Parameter	Value
Strobe frequency	0.1–10 Hz

Spot diameter



Distance	Ø 5°	Ø 60°
2 m	0.17 m	2.3 m
4 m	0.35 m	4.6 m
6 m	0.52 m	6.9 m
8 m	0.7 m	9.2 m
10 m	0.87 m	11.5 m
15 m	1.3 m	17.3 m

Spot diameter square to the beam axis, calculated from the beam angle.

11 Maintenance and cleaning

- Before cleaning and maintenance, switch the device off, disconnect it from the power supply and let it cool down.
- Clean the housing with a soft, dry or slightly damp cloth. Do not use solvents, abrasive cleaners or pressure washers, and make sure no liquid gets into the device.
- Clean optical parts (lenses, front glass), if the device has any, with a soft lint-free cloth and a cleaner intended for optics or glass.
- Regularly inspect the housing, cables, connectors and fixings. Have damaged parts replaced by a service center.
- How often to clean depends on the environment; dust, smoke and fog make the device dirty much faster.

12 Troubleshooting

Problem	Remedy
The device does not switch on	Check the supply voltage, the cables and the fuse, if the device has one.
The device does not respond to DMX	Check the start address, the selected DMX mode and whether it matches the profile in the controller, the cable connection to DMX IN, and the controller output (universe).
The device behaves erratically or flickers	Check the terminator at the end of the line, the condition and wiring of the cables (shield on pin 1 only), the number of devices on the line (32 at most), and that the line is not split without a splitter.
Only some devices on the line respond	Check the cable and connectors between the last working and the first non-working device, and make sure all devices on the line are switched on.
Devices respond to the wrong channels or affect each other	Check that the addresses do not overlap and that the DMX mode on the devices matches the patch in the controller.
The device or the connected load does not light up although it receives DMX	Check the values of the dimmer, shutter and strobe channels against the DMX channel table. For the DMX modes for which the sources state it, the chapter DMX channels gives under the mode's heading which channels must be open.
Movement is reversed	Check whether Pan/Tilt inversion is enabled in the device menu or in the controller.
Moving parts do not reach the correct position after power-on or transport	Switch the device off and on again to reset the position, and make sure the transport lock, if any, is released. If this does not help, contact a service center.
Movement is jerky	Check the value of the Pan/Tilt speed channel, if the device has one, and the stability of the DMX signal.

13 Disposal

The crossed-out wheeled bin symbol on the product, in the manual or on the packaging means that the product must not be disposed of with unsorted household waste at the end of its life.

Take the end-of-life equipment to a collection point, for example a municipal collection site or a retailer. Proper disposal enables materials to be recycled and helps prevent possible negative effects on the environment and human health.

Follow the regulations applicable in your country; in the Czech Republic, take-back is governed by Act No. 542/2020 Coll., on End-of-Life Products.

Recycle the packaging materials according to their type.