DMX REFERENCE

MiniB 7*40W

MarkeEigenbau

Manufacturer	MarkeEigenbau
GDTF file	MarkeEigenbau_MiniB_740W_140647.gdtf
GDTF revision	FINAL · 2026-04-29
Generated	2026-11-24

Contents

1 About this manual 2
2 Quick reference 3
3 Safety instructions 4
4 Product description 5
5 Installation 6
6 Connections 6
7 Operation 7
8 Functions at a glance 8
9 DMX channels 10
Mode 23ch 11
Mode 51ch 13
Mode 35CH 17
10 Technical specifications 19
11 Maintenance and cleaning 20
12 Troubleshooting 20
13 Disposal 20

1 About this manual

This document describes the MiniB 7*40W by MarkeEigenbau. It was compiled from the GDTF file MarkeEigenbau_MiniB_740W_140647.gdtf from the GDTF-Share library.

File revision: “FINAL”.

The DMX modes, the channel functions and the technical data are given as the GDTF file states them. Installation, operation from the device's control panel, service and safety instructions are described in the manufacturer's original user manual, which takes precedence over this document.

This document was not issued or endorsed by MarkeEigenbau; product names and trademarks belong to their owners.

Safety notices are marked with signal words according to the severity of the hazard: DANGER – an imminent hazard that will result in death or serious injury; WARNING – a potential hazard that could result in death or serious injury; CAUTION – a potential hazard that could result in minor injury or property damage; NOTE – additional information for correct and safe use.

> **NOTE** This product is designed for stage and effect lighting. It is not suitable for household room illumination.

2 Quick reference

Parameter	Value
Power consumption	300 W
Weight	6 kg

DMX modes

Mode	Channels	Units in one universe	First start addresses
23ch	23	22	1, 24, 47, 70, ...
51ch	51	10	1, 52, 103, 154, ...
35CH	35	14	1, 36, 71, 106, ...

No light? Check these channels

- 23ch: CH 8 Dimmer above 0; CH 9 Shutter at 0–4 “Open” or 104–107 or 208–212 or 252–255
- 51ch: CH 8 Dimmer above 0; CH 9 Shutter at 0–4 “Open” or 104–107 or 208–212 or 252–255
- 35CH: CH 12 Dimmer above 0; CH 13 Dimmer Fine above 0


Read the manual before use


Risk of electric shock


Do not stare into the light


Indoor use only

3 Safety instructions


Read the manual before use


Risk of electric shock


Do not stare into the light


Indoor use only

⚠ WARNING

- This device is intended for professional use. Installation, connection, setup and maintenance must be carried out only by suitably qualified persons who have read this manual.
- Use the device only for its intended purpose and as described in this manual.
- Do not open the housing and do not modify or tamper with the device. Refer all repairs to an authorized service center.
- Do not use the device if its housing, power or data cable, or a connector is damaged, if the device has been dropped, or if liquid or a foreign object has entered it. In such a case, have it checked by a service center.
- Disconnect the device from the power supply before cleaning, maintenance or any work on the connections.
- After moving the device from a cold to a warm environment, let it reach room temperature before switching it on to prevent condensation inside.
- The device is not a toy; keep it out of the reach of children.

⚠ WARNING

- Connect the device only to a properly installed mains outlet with a protective earth (ground) contact. The outlet or other means of disconnection must remain easily accessible.
- Power supply: 100–245 V, 50/60 Hz. Before connecting, make sure that the mains voltage matches this value and the value on the rating plate of the device.
- Do not connect the device to a dimmer or to a dimmed circuit.
- Use only the original power cable or a cable with identical ratings. Protect the cable from damage, do not run it over sharp edges, and never unplug it by pulling on the cable.
- When connecting several devices to one circuit, do not exceed its permitted load.
- Do not touch the device with wet hands.

⚠ WARNING

- This device is designed for indoor use only. Protect it from rain, splashing water, moisture and dust, and do not place containers with liquids on it.
- Do not operate the device in high humidity, near water, or where condensation can form on it.

⚠ CAUTION

- This device emits intense light. Do not look directly into the light source or the beam at close range; doing so may damage your eyes.
- Do not aim the beam at the eyes of people or animals at close range, and do not view the light source through optical instruments (binoculars, camera lenses).
- Do not aim the beam at flammable or heat-sensitive materials at close range.

> ⚠ **CAUTION**
>
> - Strobe and fast flashing light effects can trigger epileptic seizures in susceptible people (photosensitive epilepsy) and can cause nausea or disorientation.
> - Inform the audience and performers in advance that strobe effects will be used, for example with a notice at the entrance, and do not use them longer than necessary.

> ⚠ **WARNING**
>
> - The moving parts of the device (for example the head or arms) can move quickly and unexpectedly at any time – after power-on, during a reset, or on a command from the controller.
> - Keep yourself and any objects out of the range of movement. While the device is switched on, do not touch the moving parts, move them by hand, or obstruct their movement; this can cause injury (pinching) and damage the drive.
> - Do not carry the device by its moving parts. If the device has a transport lock, engage it before transport and release it before switching on.

4 Product description

Range of movement

Pan 540°

top view



Tilt 270°

side view



5 Installation

⚠ **WARNING**

- Rigging must be carried out only by qualified persons in accordance with applicable regulations, in particular those for work at height.
- The supporting structure and fixings must safely carry the weight of all suspended devices; verify their load capacity in advance.
- Weight of the device: 6 kg.
- Use suitable mounting hardware (for example truss clamps) and tighten all screw connections properly.
- Always secure the suspended device against falling with a safety cable of adequate load capacity, routed through a fixed point of the device and around the supporting structure.
- During installation and removal, keep people out of the area below the work position.
- Regularly inspect the fixings and the safety cable for damage, corrosion and loosening.

6 Connections

- Use shielded cable designed for DMX512 with an impedance of 110 Ω. Ordinary microphone cable is not suitable for DMX, especially over longer distances.
- Connect the devices in a daisy chain: connect the DMX OUT of one device to the DMX IN of the next. Do not split the line with Y-cables or wire it in a star; the line may be split only with a DMX splitter.
- Connect the shield to pin 1 only. Do not connect the shield (ground) to the metal shell of the connector; this can cause short circuits or erratic behavior.
- XLR pin assignment: pin 1 – shield (ground), pin 2 – Data- (Data Complement), pin 3 – Data+ (Data True). On 5-pin connectors, pins 4 and 5 are not connected; a 5-pin connector can be connected to a 3-pin one with a cable adapter.
- Terminate the end of the line (for impedance matching): plug an XLR connector with a 120 Ω, ¼ W resistor between pins 2 and 3 into the DMX OUT of the last device. This reduces the risk of erratic behavior.
- Connect no more than 32 devices to one DMX line. For more devices or longer runs, use a DMX splitter or booster.

DMX line



Mode 51ch: every unit occupies 51 channels from its address. At most 32 units on one line; for more units or longer runs use a DMX splitter. A 120 Ω terminator closes the last DMX OUT.

7 Operation

Setting the DMX address

- The device occupies as many consecutive channels in the DMX universe as the selected DMX mode uses, starting at the set start address.
- Number of channels occupied in the DMX mode “51ch”: 51.
- Choose start addresses so that the channels of individual devices do not overlap and the last occupied channel does not exceed 512. Devices with the same start address and mode respond identically.
- For several devices in a row in the DMX mode “51ch”, you can use, for example, the start addresses 1, 52, 103, 154.
- The DMX mode set on the device must match the fixture profile (personality) used in the controller.

8 Functions at a glance

Functions in each DMX mode

	23ch 23 channels	51ch 51 channels	35CH 35 channels
Pan / Tilt	1–3	1, 3	14, 16
Pan / Tilt resolution	16 bit	16 bit	8 bit
Dimmer	8	8	12
Shutter / strobe	9	9	11
Color mixing	10–13, 19–22	10–13, 19–22, 24–51	8 channels (1–28)
Color temperature	14	14	9
Color wheel			10
Gobo wheel	16, 17	16, 17	
Gobo rotation	18	18	
Zoom	6	6	20
Effects / macros	15	15	

Color wheel



LED colors and the colors they mix



LED	x	y
Red	0.640	0.330
Green	0.300	0.600
Blue	0.150	0.060
White	0.313	0.329

The shaded area holds the colors the LEDs can mix; the dots are the LED colors the GDTF file states.

Cells (pixels)



7 cells where the GDTF file places them (seen from above), numbered by their first DMX channel (CH) in the mode “35CH”.

9 DMX channels

Units in one DMX universe



Start addresses of 20 units in the mode “51ch”

Unit	Start address	Unit	Start address	Unit	Start address	Unit	Start address
1	1	6	256	11	U2 · 1	16	U2 · 256
2	52	7	307	12	U2 · 52	17	U2 · 307
3	103	8	358	13	U2 · 103	18	U2 · 358
4	154	9	409	14	U2 · 154	19	U2 · 409
5	205	10	460	15	U2 · 205	20	U2 · 460

Where a DMX universe is full, the next units continue in the next universe: “U2 · 1” is address 1 in the second universe, counted from the universe of the first unit.

Mode 23ch

16-bit parameters use two channels, coarse and fine: value = 256 × coarse value + fine value.

If the device receives DMX in this mode but gives no light, check these channels: CH 8 Dimmer above 0; CH 9 Shutter at 0–4 “Open” or 104–107 or 208–212 or 252–255. The GDTF file gives these values for a console's Highlight function: CH 8 Dimmer 255, CH 9 Shutter 255, CH 10 Red 1 255, CH 11 Green 1 255, CH 12 Blue 1 255, CH 13 White 1 0.

Channel functions at a glance



CH	Function	DMX	Description
1	Pan	0–127	Pan 1
		128	Home
		129–255	Pan 1
2	Pan Fine	0–127	Pan 1
		128	Home
		129–255	Pan 1
3	Tilt	0–127	Tilt 1
		128	Home
		128–255	Tilt 1
4	Tilt Fine	0–255	Fine adjustment of CH 3
5	Speed Pan/Tilt	0	Fast
		1–254	Fast ... Slow

CH	Function	DMX	Description
5	Speed Pan/Tilt (continued)	255	Slow
6	Zoom	0	Narrow
		1–254	Narrow ... Wide
		255	Wide
7	Beam Shaper	0–255	
8	Dimmer	0	Closed
		1–254	Closed ... Open
		255	Open
9	Shutter	0–4	Open
		5–15	Shutter 1 Strobe 2
		16	Slow strobo
		17–102	Slow strobo ... Fast strobo
		103	Fast strobo
		104–107	Open 1
		108–207	Strobe Mode Pulse 4
		208–212	Open 2
		213–214	Strobe Mode Random 3
		215–251	Random strobo
		252–255	Open 3
10	Red 1	0	Min
		1–254	Min ... Max
		255	Max
11	Green 1	0	Min
		1–254	Min ... Max
		255	Max
12	Blue 1	0	Min
		1–254	Min ... Max
		255	Max
13	White 1	0	Min
		1–254	Min ... Max
		255	Max
14	CTO	0–255	
15	Color Macro	0–49	No function
		50–99	Skip change
		100–255	Gradual change
16	Gobo	0–255	
17	Gobo 2	0–255	
18	Gobo 2 Rotation	0–255	
19	Red 2	0–255	
20	Green 2	0–255	
21	Blue 2	0–255	

CH	Function	DMX	Description
22	White 2	0–255	
23	Control	0–127	No function
		128–255	Reset

Mode 51ch

16-bit parameters use two channels, coarse and fine: value = 256 × coarse value + fine value.

If the device receives DMX in this mode but gives no light, check these channels: CH 8 Dimmer above 0; CH 9 Shutter at 0–4 “Open” or 104–107 or 208–212 or 252–255. The GDTF file gives these values for a console's Highlight function: CH 8 Dimmer 255, CH 9 Shutter 255, CH 10 Red 1 255, CH 11 Green 1 255, CH 12 Blue 1 255, CH 13 White 1 0, CH 24 Red 3 255, CH 25 Green 3 255, CH 26 Blue 3 255, CH 27 White 3 0, CH 28 Red 4 255, CH 29 Green 4 255, CH 30 Blue 4 255, CH 31 White 4 0, CH 32 Red 5 255, CH 33 Green 5 255, CH 34 Blue 5 255, CH 35 White 5 0, CH 36 Red 6 255, CH 37 Green 6 255, CH 38 Blue 6 255, CH 39 White 6 0, CH 40 Red 7 255, CH 41 Green 7 255, CH 42 Blue 7 255, CH 43 White 7 0, CH 44 Red 8 255, CH 45 Green 8 255, CH 46 Blue 8 255, CH 47 White 8 0, CH 48 Red 9 255, CH 49 Green 9 255, CH 50 Blue 9 255, CH 51 White 9 0.

Channel functions at a glance



CH	Function	DMX	Description
1	Pan	0–127	Pan 1
		128	Home
		128–255	Pan 1

CH	Function	DMX	Description
2	Pan Fine	0–255	Fine adjustment of CH 1
3	Tilt		Same as CH 3 in the mode “23ch” (p. 11)
4	Tilt Fine	0–255	Fine adjustment of CH 3
5	Speed Pan/Tilt		Same as CH 5 in the mode “23ch” (p. 11)
6	Zoom		Same as CH 6 in the mode “23ch” (p. 12)
7	Beam Shaper	0–255	
8	Dimmer		Same as CH 8 in the mode “23ch” (p. 12)
9	Shutter		Same as CH 9 in the mode “23ch” (p. 12)
10	Red 1		Same as CH 10 in the mode “23ch” (p. 12)
11	Green 1		Same as CH 11 in the mode “23ch” (p. 12)
12	Blue 1		Same as CH 12 in the mode “23ch” (p. 12)
13	White 1		Same as CH 13 in the mode “23ch” (p. 12)
14	CTO	0–255	
15	Color Macro		Same as CH 15 in the mode “23ch” (p. 12)
16	Gobo	0–255	
17	Gobo 2	0–255	
18	Gobo 2 Rotation	0–255	
19	Red 2	0–255	
20	Green 2	0–255	
21	Blue 2	0–255	
22	White 2	0–255	
23	Control		Same as CH 23 in the mode “23ch” (p. 13)
24	Red 3	0	Min
		1–254	Min … Max
		255	Max
25	Green 3	0	Min
		1–254	Min … Max
		255	Max
26	Blue 3	0	Min
		1–254	Min … Max
		255	Max
27	White 3	0	Min
		1–254	Min … Max
		255	Max
28	Red 4	0	Min
		1–254	Min … Max
		255	Max
29	Green 4	0	Min
		1–254	Min … Max
		255	Max
30	Blue 4	0	Min

CH	Function	DMX	Description
30	Blue 4 (continued)	1–254	Min … Max
		255	Max
31	White 4	0	Min
		1–254	Min … Max
		255	Max
32	Red 5	0	Min
		1–254	Min … Max
		255	Max
33	Green 5	0	Min
		1–254	Min … Max
		255	Max
34	Blue 5	0	Min
		1–254	Min … Max
		255	Max
35	White 5	0	Min
		1–254	Min … Max
		255	Max
36	Red 6	0	Min
		1–254	Min … Max
		255	Max
37	Green 6	0	Min
		1–254	Min … Max
		255	Max
38	Blue 6	0	Min
		1–254	Min … Max
		255	Max
39	White 6	0	Min
		1–254	Min … Max
		255	Max
40	Red 7	0	Min
		1–254	Min … Max
		255	Max
41	Green 7	0	Min
		1–254	Min … Max
		255	Max
42	Blue 7	0	Min
		1–254	Min … Max
		255	Max
43	White 7	0	Min
		1–254	Min … Max
		255	Max

CH	Function	DMX	Description
44	Red 8	0	Min
		1–254	Min … Max
		255	Max
45	Green 8	0	Min
		1–254	Min … Max
		255	Max
46	Blue 8	0	Min
		1–254	Min … Max
		255	Max
47	White 8	0	Min
		1–254	Min … Max
		255	Max
48	Red 9	0	Min
		1–254	Min … Max
		255	Max
49	Green 9	0	Min
		1–254	Min … Max
		255	Max
50	Blue 9	0	Min
		1–254	Min … Max
		255	Max
51	White 9	0	Min
		1–254	Min … Max
		255	Max

Mode 35CH

If the device receives DMX in this mode but gives no light, check these channels: CH 12 Dimmer above 0; CH 13 Dimmer Fine above 0. The GDTF file gives these values for a console's Highlight function: CH 7 White 1 0, CH 11 Shutter 255, CH 12 Dimmer 254.

Channel functions at a glance



Channel functions at a glance



CH	Function	DMX	Description
1	Red 1	0–255	
2	R Fine 1	0–255	
3	Green 1	0–255	
4	G Fine	0–255	G fine
5	Blue 1	0–255	
6	B Fine	0–255	B fine
7	White 1	0–255	
8	W Fine	0–255	
9	CTO	0–255	8000–2500 K
10	Color Macro	0–255	Color Macro
11	Shutter	0–3	Closed
		4–255	Shutter
12	Dimmer	0–255	
13	Dimmer Fine	0–255	
14	Pan	0–127	Pan 1
		128	HOME
		129–255	Pan 1
15	Pan Fine	0–255	
16	Tilt	0–127	Tilt 1
		128	Home
		129–255	Tilt 1
17	Tilt Fine	0–255	
18	Function	0–127	Fixture Global Reset
		128–255	Reset
19	Reset	0–25	No Function
		26–76	Zoom Reset
		77–127	Position Reset
		128–255	Reset
20	Zoom	0–255	
21	Lens Rotation	0–255	
22	Shape Selection 1	0–255	
23	Shape Speed	0–255	
24	Shape Fade	0–255	
25	Red 2	0–255	
26	Green 2	0–255	
27	Blue 2	0–255	
28	White 2	0–255	
29	Foreground Dimmer		Shape Dimmer 1
		0–255	Shape Dimmer 1
30	Background Dim	0–255	
31	Shape Transition	0–255	

CH	Function	DMX	Description
32	Shape Offset	0–255	
33	Foreground Shutter	0–255	
34	Background Shutter	0–255	
35	Shape Selection 2	0–255	

10 Technical specifications

Parameter	Value
Optics	
Zoom	3.3–55°
Movement	
Pan	540°
Tilt	270°
Control	
DMX connection	3-pin XLR IN/OUT
Electrical	
Power supply	100–245 V, 50/60 Hz
Power consumption	300 W
Power connectors	NAC3FCA IN, NAC3FCB OUT
Dimensions and construction	
Weight	6 kg
Operating environment	
Operating temperature	0 to 40 °C

Speeds and ranges

Parameter	Value
Color temperature range	2500–8000 K
Strobe frequency	1–25 Hz

Spot diameter



Distance	Ø 3.3°	Ø 55°
2 m	0.12 m	2.1 m
4 m	0.23 m	4.2 m
6 m	0.35 m	6.2 m
8 m	0.46 m	8.3 m
10 m	0.58 m	10.4 m
15 m	0.86 m	15.6 m

Spot diameter square to the beam axis, calculated from the beam angle.

11 Maintenance and cleaning

- Before cleaning and maintenance, switch the device off, disconnect it from the power supply and let it cool down.
- Clean the housing with a soft, dry or slightly damp cloth. Do not use solvents, abrasive cleaners or pressure washers, and make sure no liquid gets into the device.
- Clean optical parts (lenses, front glass), if the device has any, with a soft lint-free cloth and a cleaner intended for optics or glass.
- Regularly inspect the housing, cables, connectors and fixings. Have damaged parts replaced by a service center.
- How often to clean depends on the environment; dust, smoke and fog make the device dirty much faster.

12 Troubleshooting

Problem	Remedy
The device does not switch on	Check the supply voltage, the cables and the fuse, if the device has one.
The device does not respond to DMX	Check the start address, the selected DMX mode and whether it matches the profile in the controller, the cable connection to DMX IN, and the controller output (universe).
The device behaves erratically or flickers	Check the terminator at the end of the line, the condition and wiring of the cables (shield on pin 1 only), the number of devices on the line (32 at most), and that the line is not split without a splitter.
Only some devices on the line respond	Check the cable and connectors between the last working and the first non-working device, and make sure all devices on the line are switched on.
Devices respond to the wrong channels or affect each other	Check that the addresses do not overlap and that the DMX mode on the devices matches the patch in the controller.
The device or the connected load does not light up although it receives DMX	Check the values of the dimmer, shutter and strobe channels against the DMX channel table. For the DMX modes for which the sources state it, the chapter DMX channels gives under the mode's heading which channels must be open.
Movement is reversed	Check whether Pan/Tilt inversion is enabled in the device menu or in the controller.
Moving parts do not reach the correct position after power-on or transport	Switch the device off and on again to reset the position, and make sure the transport lock, if any, is released. If this does not help, contact a service center.
Movement is jerky	Check the value of the Pan/Tilt speed channel, if the device has one, and the stability of the DMX signal.

13 Disposal

The crossed-out wheeled bin symbol on the product, in the manual or on the packaging means that the product must not be disposed of with unsorted household waste at the end of its life.

Take the end-of-life equipment to a collection point, for example a municipal collection site or a retailer. Proper disposal enables materials to be recycled and helps prevent possible negative effects on the environment and human health.

Follow the regulations applicable in your country; in the Czech Republic, take-back is governed by Act No. 542/2020 Coll., on End-of-Life Products.

Recycle the packaging materials according to their type.