DMX REFERENCE

EclExpoFL300VW

Prolights



Manufacturer	Prolights
GDTF file	Prolights_EclExpoFL300VW_168709.gdtf
GDTF revision	Rev 010 - CC Updated as FW 2_0 - Custom attributes alignment · 2026-11-10
Generated	2026-11-24

Contents

1 About this manual 2
2 Quick reference 3
3 Safety instructions 4
4 Product description 4
5 Installation 5
6 Connections 5
7 Operation 6
8 Functions at a glance 6
9 DMX channels 8
Mode UNO 8
Mode DUO 9
Mode Standard 9
Mode Basic 10
Mode Extended 10
10 Technical specifications 13
11 Maintenance and cleaning 13
12 Troubleshooting 14
13 Disposal 14

1 About this manual

This document describes the EclExpoFL300VW by Prolights. It was compiled from the GDTF file Prolights_EclExpoFL300VW_168709.gdtf from the GDTF-Share library.

File revision: “Rev 010 - CC Updated as FW 2_0 - Custom attributes alignment”.

The DMX modes, the channel functions and the technical data are given as the GDTF file states them. Installation, operation from the device's control panel, service and safety instructions are described in the manufacturer's original user manual, which takes precedence over this document.

This document was not issued or endorsed by Prolights; product names and trademarks belong to their owners.

Safety notices are marked with signal words according to the severity of the hazard: DANGER – an imminent hazard that will result in death or serious injury; WARNING – a potential hazard that could result in death or serious injury; CAUTION – a potential hazard that could result in minor injury or property damage; NOTE – additional information for correct and safe use.

> **NOTE** This product is designed for stage and effect lighting. It is not suitable for household room illumination.

2 Quick reference

Parameter	Value
Weight	5.5 kg

DMX modes

Mode	Channels	Units in one universe	First start addresses
UNO	1	512	1, 2, 3, 4, ...
DUO	2	256	1, 3, 5, 7, ...
Standard	5	102	1, 6, 11, 16, ...
Basic	3	170	1, 4, 7, 10, ...
Extended	11	46	1, 12, 23, 34, ...

No light? Check these channels

- UNO: CH 1 Dimmer above 0
- DUO: CH 1 Dimmer above 0
- Standard: CH 1 Dimmer above 0; CH 3 Shutter at 63–64, 126–127, 189–190 or 252–255 “Open”
- Basic: CH 1 Dimmer above 0
- Extended: CH 1 Dimmer above 0; CH 3 Shutter at 63–64, 126–127, 189–190 or 252–255 “Open”


Read the manual before use


Do not stare into the light


Indoor use only

3 Safety instructions



Read the manual before use



Do not stare into the light



Indoor use only

⚠ WARNING

- This device is intended for professional use. Installation, connection, setup and maintenance must be carried out only by suitably qualified persons who have read this manual.
- Use the device only for its intended purpose and as described in this manual.
- Do not open the housing and do not modify or tamper with the device. Refer all repairs to an authorized service center.
- Do not use the device if its housing, power or data cable, or a connector is damaged, if the device has been dropped, or if liquid or a foreign object has entered it. In such a case, have it checked by a service center.
- Disconnect the device from the power supply before cleaning, maintenance or any work on the connections.
- After moving the device from a cold to a warm environment, let it reach room temperature before switching it on to prevent condensation inside.
- The device is not a toy; keep it out of the reach of children.

⚠ WARNING

- This device is designed for indoor use only. Protect it from rain, splashing water, moisture and dust, and do not place containers with liquids on it.
- Do not operate the device in high humidity, near water, or where condensation can form on it.

⚠ CAUTION

- This device emits intense light. Do not look directly into the light source or the beam at close range; doing so may damage your eyes.
- Do not aim the beam at the eyes of people or animals at close range, and do not view the light source through optical instruments (binoculars, camera lenses).
- Do not aim the beam at flammable or heat-sensitive materials at close range.

⚠ CAUTION

- Strobe and fast flashing light effects can trigger epileptic seizures in susceptible people (photosensitive epilepsy) and can cause nausea or disorientation.
- Inform the audience and performers in advance that strobe effects will be used, for example with a notice at the entrance, and do not use them longer than necessary.

4 Product description

Description in the GDTF file

“The EclExpo Flood300VW is a variable white LED Floodlight, designed for exhibitions and showrooms, as a high-quality LED replacement of traditional tungsten, CDM or HMI asymmetric luminaires. The EclExpo Flood300VW has a 300W LED source, with variable white ranging from 2,700K to 6,500K, and an

outstanding lumen output with high-scoring CRI levels (>95), TM-30, R9. Combined with a reflector, it has a wide asymmetric beam angle of 100° (Horizontal) x 60° (Vertical) of indirect light emission. This unit is incredibly user-friendly, using remote control via DMX and RDM (XLR 5p in & through) or intuitive stand-alone operation through an on-board display and two rotatory knobs CCT and dimmer settings. Its unique design and performance set a new standard for exhibition floodlights."

5 Installation

⚠ **WARNING**

- Rigging must be carried out only by qualified persons in accordance with applicable regulations, in particular those for work at height.
- The supporting structure and fixings must safely carry the weight of all suspended devices; verify their load capacity in advance.
- Weight of the device: 5.5 kg.
- Use suitable mounting hardware (for example truss clamps) and tighten all screw connections properly.
- Always secure the suspended device against falling with a safety cable of adequate load capacity, routed through a fixed point of the device and around the supporting structure.
- During installation and removal, keep people out of the area below the work position.
- Regularly inspect the fixings and the safety cable for damage, corrosion and loosening.

6 Connections

- Use shielded cable designed for DMX512 with an impedance of 110 Ω. Ordinary microphone cable is not suitable for DMX, especially over longer distances.
- Connect the devices in a daisy chain: connect the DMX OUT of one device to the DMX IN of the next. Do not split the line with Y-cables or wire it in a star; the line may be split only with a DMX splitter.
- Connect the shield to pin 1 only. Do not connect the shield (ground) to the metal shell of the connector; this can cause short circuits or erratic behavior.
- XLR pin assignment: pin 1 – shield (ground), pin 2 – Data- (Data Complement), pin 3 – Data+ (Data True). On 5-pin connectors, pins 4 and 5 are not connected; a 5-pin connector can be connected to a 3-pin one with a cable adapter.
- Terminate the end of the line (for impedance matching): plug an XLR connector with a 120 Ω, ¼ W resistor between pins 2 and 3 into the DMX OUT of the last device. This reduces the risk of erratic behavior.
- Connect no more than 32 devices to one DMX line. For more devices or longer runs, use a DMX splitter or booster.

DMX line



Mode Extended: every unit occupies 11 channels from its address. At most 32 units on one line; for more units or longer runs use a DMX splitter. A 120 Ω terminator closes the last DMX OUT.

7 Operation

Setting the DMX address

- The device occupies as many consecutive channels in the DMX universe as the selected DMX mode uses, starting at the set start address.
- Number of channels occupied in the DMX mode “Extended”: 11.
- Choose start addresses so that the channels of individual devices do not overlap and the last occupied channel does not exceed 512. Devices with the same start address and mode respond identically.
- For several devices in a row in the DMX mode “Extended”, you can use, for example, the start addresses 1, 12, 23, 34.
- The DMX mode set on the device must match the fixture profile (personality) used in the controller.
- The device supports RDM (Remote Device Management), two-way communication with the controller over the DMX line.

8 Functions at a glance

Functions in each DMX mode

	UNO 1 channel	DUO 2 channels	Standard 5 channels	Basic 3 channels	Extended 11 channels
Dimmer	1	1	1	1	1
Dimmer resolution	8 bit	8 bit	16 bit	8 bit	16 bit
Shutter / strobe			3		3
Color mixing				2, 3	7, 9
Color temperature		2	4		4

LED colors



LED	x	y
Warm White Led	0.472	0.414
Cold White Led	0.316	0.319

The dots are the LED colors the GDTF file states.

Spectra of the light sources



Relative spectrum of each light source as the GDTF file states it; each curve is scaled to its own maximum.

Strobe rate



9 DMX channels

Units in one DMX universe



Start addresses of 20 units in the mode “Extended”

Unit	Start address	Unit	Start address	Unit	Start address	Unit	Start address
1	1	6	56	11	111	16	166
2	12	7	67	12	122	17	177
3	23	8	78	13	133	18	188
4	34	9	89	14	144	19	199
5	45	10	100	15	155	20	210

RDM personalities

Mode	Channels	RDM personality
UNO	1	1
DUO	2	2
Standard	5	4
Basic	3	3
Extended	11	5

Mode UNO

If the device receives DMX in this mode but gives no light, check these channels: CH 1 Dimmer above 0. The GDTF file gives these values for a console's Highlight function: CH 1 Dimmer 255.

Channel functions at a glance



CH	Function	DMX	Description
1	Dimmer	0	Closed
		1–254	Closed ... Open
		255	Open

Mode DUO

If the device receives DMX in this mode but gives no light, check these channels: CH 1 Dimmer above 0. The GDTF file gives these values for a console's Highlight function: CH 1 Dimmer 255.

Channel functions at a glance



CH	Function	DMX	Description
1	Dimmer		Same as CH 1 in the mode “UNO” (p. 9)
2	Color Temperature	0	2700K
		1–254	2700K ... 6500K
		255	6500K

Mode Standard

16-bit parameters use two channels, coarse and fine: value = 256 × coarse value + fine value.

If the device receives DMX in this mode but gives no light, check these channels: CH 1 Dimmer above 0; CH 3 Shutter at 63–64, 126–127, 189–190 or 252–255 “Open”. The GDTF file gives these values for a console's Highlight function: CH 1 Dimmer 255, CH 3 Shutter 255.

Channel functions at a glance



CH	Function	DMX	Description
1	Dimmer	0–255	Closed ... Open
		255	Open
2	Dimmer Fine	0–255	Fine adjustment of CH 1
3	Shutter	0–1	Closed
		2–62	Strobe (0.9–20 Hz)
		63–64	Open_1: Open
		65–125	Pulse In Strobe (0.8–6.6 Hz)
		126–127	Open_2: Open
		128–188	Pulse Out Strobe (0.8–6.6 Hz)
		189–190	Open_3: Open

CH	Function	DMX	Description
3	Shutter (continued)	191–251	Random Strobe (0.9–20 Hz)
		252–255	Open
4	Color Temperature	0–255	2700K ... 6500K
		255	6500K
5	Color Temperature Fine	0–255	Fine adjustment of CH 4

Mode Basic

If the device receives DMX in this mode but gives no light, check these channels: CH 1 Dimmer above 0. The GDTF file gives these values for a console's Highlight function: CH 1 Dimmer 255, CH 2 Warm White 255, CH 3 Cool White 255.

Channel functions at a glance



CH	Function	DMX	Description
1	Dimmer		Same as CH 1 in the mode “UNO” (p. 9)
2	Warm White	0	Min
		1–254	Min ... Max
		255	Max
3	Cool White	0	Min
		1–254	Min ... Max
		255	Max

Mode Extended

16-bit parameters use two channels, coarse and fine: value = 256 × coarse value + fine value.

If the device receives DMX in this mode but gives no light, check these channels: CH 1 Dimmer above 0; CH 3 Shutter at 63–64, 126–127, 189–190 or 252–255 “Open”. The GDTF file gives these values for a console's Highlight function: CH 1 Dimmer 255, CH 3 Shutter 255.

Channel functions at a glance



CH	Function	DMX	Description
1	Dimmer		Same as CH 1 in the mode “Standard” (p. 9)
2	Dimmer Fine	0–255	Fine adjustment of CH 1
3	Shutter		Same as CH 3 in the mode “Standard” (p. 9)
4	Color Temperature		Same as CH 4 in the mode “Standard” (p. 10)
5	Color Temperature Fine	0–255	Fine adjustment of CH 4
6	CCT-Colors	0	CTC
		1–254	CTC ... ColorMix
		255	ColorMix
7	Warm White	0–255	Min ... Max
		255	Max
8	Warm White Fine	0–255	Fine adjustment of CH 7
9	Cool White	0–255	Min ... Max
		255	Max
10	Cool White Fine	0–255	Fine adjustment of CH 9
11	Control	0–1	No function
		2–3	Display ON
		4–5	Display 10s
		6–7	Display 20s
		8–9	Display 30s
		10–11	Flip Display ON
		12–13	Flip Display OFF
		14–15	Key Lock ON
		16–17	Key Lock OFF
		18–19	Linear
		20–21	S-Curve
		22–23	Square Law
		24–25	Inverse Square Law
		26–27	Auto
		28–29	Dimmer Mode: Slow
		30–31	Medium
		32–33	Dimmer Mode: Fast
		34–35	White Calibration: OFF
		36–37	MANUAL
		38–39	600Hz
		40–41	1200Hz
		42–43	2000Hz
		44–45	4000Hz
		46–47	6000Hz
		48–49	25kHz
		50–51	BlackOut
		52–53	Hold

CH	Function	DMX	Description
11	Control (continued)	54–55	StandAlone
		56–57	AUTO
		58–59	Silent
		60–61	Fan Mode: High
		62–63	Fan Mode: OFF
		64–65	Master DMX
		66–67	Master NO DMX
		68–69	Slave
		70–71	Effect
		72–73	CCT
		74–75	WW+CW
		76–77	White Preset
		78–79	Fixed Color
		80–81	Color Temperature
		82–83	Manual Color
		84–85	Menu Stand Alone
		86–87	Constant
		88–89	Dynamic
		90–91	Dimmer Speed OFF
		92–253	Reserved
		254–255	FACTORY DEFAULT OF ALL CONTROLLED FUNCTION

10 Technical specifications

Parameter	Value
Light	
Light source	LED
LED power	300 W
Luminous flux	13,044 lm
Color temperature	4,100 K
Color rendering index (CRI)	96
Optics	
Beam angle	68.8°
Control	
DMX connection	5-pin XLR IN/OUT
RDM	yes (manufacturer ID 0x15D0, device model ID 0xD072)
Electrical	
Power connectors	powerCON TRUE1 IN/OUT
Dimensions and construction	
Weight	5.5 kg
Operating environment	
Operating temperature	-10 to 45 °C

Speeds and ranges

Parameter	Value
Color temperature range	2700–6500 K
Strobe frequency	0.9–20 Hz

Spot diameter



Distance	Ø 68.8°
2 m	2.7 m
4 m	5.5 m
6 m	8.2 m
8 m	11 m
10 m	13.7 m
15 m	20.5 m

Spot diameter square to the beam axis, calculated from the beam angle.

11 Maintenance and cleaning

- Before cleaning and maintenance, switch the device off, disconnect it from the power supply and let it cool down.
- Clean the housing with a soft, dry or slightly damp cloth. Do not use solvents, abrasive cleaners or

pressure washers, and make sure no liquid gets into the device.

- Clean optical parts (lenses, front glass), if the device has any, with a soft lint-free cloth and a cleaner intended for optics or glass.
- Regularly inspect the housing, cables, connectors and fixings. Have damaged parts replaced by a service center.
- How often to clean depends on the environment; dust, smoke and fog make the device dirty much faster.

12 Troubleshooting

Problem	Remedy
The device does not switch on	Check the supply voltage, the cables and the fuse, if the device has one.
The device does not respond to DMX	Check the start address, the selected DMX mode and whether it matches the profile in the controller, the cable connection to DMX IN, and the controller output (universe).
The device behaves erratically or flickers	Check the terminator at the end of the line, the condition and wiring of the cables (shield on pin 1 only), the number of devices on the line (32 at most), and that the line is not split without a splitter.
Only some devices on the line respond	Check the cable and connectors between the last working and the first non-working device, and make sure all devices on the line are switched on.
Devices respond to the wrong channels or affect each other	Check that the addresses do not overlap and that the DMX mode on the devices matches the patch in the controller.
The device or the connected load does not light up although it receives DMX	Check the values of the dimmer, shutter and strobe channels against the DMX channel table. For the DMX modes for which the sources state it, the chapter DMX channels gives under the mode's heading which channels must be open.

13 Disposal

The crossed-out wheeled bin symbol on the product, in the manual or on the packaging means that the product must not be disposed of with unsorted household waste at the end of its life.

Take the end-of-life equipment to a collection point, for example a municipal collection site or a retailer. Proper disposal enables materials to be recycled and helps prevent possible negative effects on the environment and human health.

Follow the regulations applicable in your country; in the Czech Republic, take-back is governed by Act No. 542/2020 Coll., on End-of-Life Products.

Recycle the packaging materials according to their type.