DMX REFERENCE

Neptune 400 Wash

Silver Star Neptune 400 Wash

Silver Star



Manufacturer	Silver Star
GDTF file	Silver_Star_Neptune_400_Wash_44416.gdtf
GDTF revision	1.01 · 2023-07-28
Generated	2026-11-24

Contents

1 About this manual 2
2 Quick reference 3
3 Safety instructions 4
4 Product description 5
5 Installation 5
6 Connections 6
7 Operation 6
8 Functions at a glance 7
9 DMX channels 9
Mode SSP 10
Mode HSIC 14
Mode TR16 16
Mode CMY 23
Mode Tour 25
Mode Pixel 26
10 Technical specifications 28
11 Maintenance and cleaning 28
12 Troubleshooting 29
13 Disposal 29

1 About this manual

This document describes the Silver Star Neptune 400 Wash by Silver Star. It was compiled from the GDTF file Silver_Star_Neptune_400_Wash_44416.gdtf from the GDTF-Share library.

File revision: “1.01”.

The DMX modes, the channel functions and the technical data are given as the GDTF file states them. Installation, operation from the device's control panel, service and safety instructions are described in the manufacturer's original user manual, which takes precedence over this document.

This document was not issued or endorsed by Silver Star; product names and trademarks belong to their owners.

Safety notices are marked with signal words according to the severity of the hazard: DANGER – an imminent hazard that will result in death or serious injury; WARNING – a potential hazard that could result in death or serious injury; CAUTION – a potential hazard that could result in minor injury or property damage; NOTE – additional information for correct and safe use.

> **NOTE** This product is designed for stage and effect lighting. It is not suitable for household room illumination.

2 Quick reference

Parameter	Value
Weight	23 kg

DMX modes

Mode	Channels	Units in one universe	First start addresses
SSP	18	28	1, 19, 37, 55, ...
HSIC	20	25	1, 21, 41, 61, ...
TR16	29	17	1, 30, 59, 88, ...
CMY	23	22	1, 24, 47, 70, ...
Tour	22	23	1, 23, 45, 67, ...
Pixel	92	5	1, 93, 185, 277, ...

No light? Check these channels

- SSP: CH 8 Dimmer 1 above 0; CH 9 Shutter at 0–9, 100–109 or 180–189 “Open”; CH 17 Dimmer 2 above 0
- HSIC: CH 6 Dimmer 1 above 0; CH 11 Shutter at 0–9, 100–109 or 180–189 “Open”; CH 19 Dimmer 2 above 0
- TR16: CH 14 Dimmer 1 above 0; CH 16 Shutter at 0–9, 100–109 or 180–189 “Open”; CH 28 Dimmer 2 above 0
- CMY: CH 9 Dimmer 1 above 0; CH 10 Shutter at 0–9, 100–109 or 180–189 “Open”; CH 22 Dimmer 2 above 0
- Tour: CH 8 Dimmer 1 above 0; CH 9 Shutter at 0–9, 100–109 or 180–189 “Open”; CH 21 Dimmer 2 above 0
- Pixel: CH 13 Dimmer 1 above 0; CH 15 Dimmer 2 above 0; CH 16 Shutter at 0–9, 100–109 or 180–189 “Open”



Read the manual before use



Do not stare into the light



Indoor use only

3 Safety instructions



Read the manual before use



Do not stare into the light



Indoor use only

⚠ WARNING

- This device is intended for professional use. Installation, connection, setup and maintenance must be carried out only by suitably qualified persons who have read this manual.
- Use the device only for its intended purpose and as described in this manual.
- Do not open the housing and do not modify or tamper with the device. Refer all repairs to an authorized service center.
- Do not use the device if its housing, power or data cable, or a connector is damaged, if the device has been dropped, or if liquid or a foreign object has entered it. In such a case, have it checked by a service center.
- Disconnect the device from the power supply before cleaning, maintenance or any work on the connections.
- After moving the device from a cold to a warm environment, let it reach room temperature before switching it on to prevent condensation inside.
- The device is not a toy; keep it out of the reach of children.

⚠ WARNING

- This device is designed for indoor use only. Protect it from rain, splashing water, moisture and dust, and do not place containers with liquids on it.
- Do not operate the device in high humidity, near water, or where condensation can form on it.

⚠ CAUTION

- This device emits intense light. Do not look directly into the light source or the beam at close range; doing so may damage your eyes.
- Do not aim the beam at the eyes of people or animals at close range, and do not view the light source through optical instruments (binoculars, camera lenses).
- Do not aim the beam at flammable or heat-sensitive materials at close range.

⚠ CAUTION

- Strobe and fast flashing light effects can trigger epileptic seizures in susceptible people (photosensitive epilepsy) and can cause nausea or disorientation.
- Inform the audience and performers in advance that strobe effects will be used, for example with a notice at the entrance, and do not use them longer than necessary.

⚠ WARNING

- The moving parts of the device (for example the head or arms) can move quickly and unexpectedly at any time – after power-on, during a reset, or on a command from the controller.
- Keep yourself and any objects out of the range of movement. While the device is switched on, do not touch the moving parts, move them by hand, or obstruct their movement; this can cause injury (pinching) and damage the drive.
- Do not carry the device by its moving parts. If the device has a transport lock, engage it before transport and release it before switching on.

4 Product description


Description in the GDTF file

“LED Wash Light fixture, 7x40W RGBL LED emitters with LED Pixel Ring”

Range of movement


Pan 540°

top view



Tilt 220°

side view



5 Installation


⚠ WARNING

- Rigging must be carried out only by qualified persons in accordance with applicable regulations, in particular those for work at height.
- The supporting structure and fixings must safely carry the weight of all suspended devices; verify their load capacity in advance.
- Weight of the device: 23 kg.
- Use suitable mounting hardware (for example truss clamps) and tighten all screw connections properly.
- Always secure the suspended device against falling with a safety cable of adequate load capacity, routed through a fixed point of the device and around the supporting structure.
- During installation and removal, keep people out of the area below the work position.
- Regularly inspect the fixings and the safety cable for damage, corrosion and loosening.

6 Connections

- Use shielded cable designed for DMX512 with an impedance of 110 Ω. Ordinary microphone cable is not suitable for DMX, especially over longer distances.
- Connect the devices in a daisy chain: connect the DMX OUT of one device to the DMX IN of the next. Do not split the line with Y-cables or wire it in a star; the line may be split only with a DMX splitter.
- Connect the shield to pin 1 only. Do not connect the shield (ground) to the metal shell of the connector; this can cause short circuits or erratic behavior.
- XLR pin assignment: pin 1 – shield (ground), pin 2 – Data- (Data Complement), pin 3 – Data+ (Data True). On 5-pin connectors, pins 4 and 5 are not connected; a 5-pin connector can be connected to a 3-pin one with a cable adapter.
- Terminate the end of the line (for impedance matching): plug an XLR connector with a 120 Ω, ¼ W resistor between pins 2 and 3 into the DMX OUT of the last device. This reduces the risk of erratic behavior.
- Connect no more than 32 devices to one DMX line. For more devices or longer runs, use a DMX splitter or booster.

DMX line



Mode Pixel: every unit occupies 92 channels from its address. At most 32 units on one line; for more units or longer runs use a DMX splitter. A 120 Ω terminator closes the last DMX OUT.

7 Operation

Setting the DMX address


- The device occupies as many consecutive channels in the DMX universe as the selected DMX mode uses, starting at the set start address.
- Number of channels occupied in the DMX mode “Pixel”: 92.
- Choose start addresses so that the channels of individual devices do not overlap and the last occupied channel does not exceed 512. Devices with the same start address and mode respond identically.
- For several devices in a row in the DMX mode “Pixel”, you can use, for example, the start addresses 1, 93, 185, 277.
- The DMX mode set on the device must match the fixture profile (personality) used in the controller.

8 Functions at a glance

Functions in each DMX mode

	SSP 18 channels	HSIC 20 channels	TR16 29 channels	CMY 23 channels	Tour 22 channels	Pixel 92 channels
Pan / Tilt	1, 2	1, 3	1, 3	1, 3	1, 2	1, 3
Pan / Tilt resolution	8 bit	16 bit	16 bit	16 bit	8 bit	16 bit
Dimmer	8, 17	6, 19	14, 28	9, 22	8, 21	13, 15
Dimmer resolution	8 bit	8 bit	16 bit	8 bit	8 bit	8 bit
Shutter / strobe	9	11	16	10	9	16
Color mixing	4–7, 11–13	13–15	7 channels (6–24)	6–8, 16–18	4–7, 15–17	7–9, 17–92
Color temperature		10				
Zoom	10	12	21	15	14	6
Effects / macros	14–16	16–18	17, 19, 20, 25–27	11, 13, 14, 19–21	10, 12, 13, 18–20	10–12


LED colors and the colors they mix




LED	x	y
Red	0.640	0.330
Green	0.300	0.600
Blue	0.150	0.060
Lime	0.321	0.416

The shaded area holds the colors the LEDs can mix; the dots are the LED colors the GDTF file states.

Strobe rate




Cells (pixels)



19 cells where the GDTF file places them (seen from above), numbered by their first DMX channel (CH) in the mode “TR16”.

9 DMX channels

Units in one DMX universe



Start addresses of 20 units in the mode “Pixel”


Unit	Start address	Unit	Start address	Unit	Start address	Unit	Start address
1	1	6	U2 · 1	11	U3 · 1	16	U4 · 1
2	93	7	U2 · 93	12	U3 · 93	17	U4 · 93
3	185	8	U2 · 185	13	U3 · 185	18	U4 · 185
4	277	9	U2 · 277	14	U3 · 277	19	U4 · 277
5	369	10	U2 · 369	15	U3 · 369	20	U4 · 369

Where a DMX universe is full, the next units continue in the next universe: “U2 · 1” is address 1 in the second universe, counted from the universe of the first unit.

Mode SSP

If the device receives DMX in this mode but gives no light, check these channels: CH 8 Dimmer 1 above 0; CH 9 Shutter at 0–9, 100–109 or 180–189 “Open”; CH 17 Dimmer 2 above 0. The GDTF file gives these values for a console's Highlight function: CH 4 Red 1 255, CH 5 Green 1 255, CH 6 Blue 1 255, CH 7 White 0, CH 8 Dimmer 1 255, CH 9 Shutter 0.

Channel functions at a glance



CH	Function	DMX	Description
1	Pan	0–126	Pan 1
		127	Home
		128–255	Pan 1
2	Tilt	0–126	Tilt 1
		127	Home
		128–255	Tilt 1
3	Speed Pan/Tilt	0	Fast
		1–254	Fast ... Slow
		255	Slow
4	Red 1	0	0%
		1–63	0% ... 25%
		64	25%
		65–127	25% ... 50%
		128	50%
		129–191	50% ... 75%
		192	75%
		193–254	75% ... 100%
		255	100%
5	Green 1	0	0%
		1–63	0% ... 25%
		64	25%
		65–127	25% ... 50%
		128	50%

CH	Function	DMX	Description
5	Green 1 (continued)	129–191	50% … 75%
		192	75%
		193–254	75% … 100%
		255	100%
6	Blue 1	0	0%
		1–63	0% … 25%
		64	25%
		65–127	25% … 50%
		128	50%
		129–191	50% … 75%
		192	75%
		193–254	75% … 100%
		255	100%
7	White		Color Add White
		0	0%
		1–63	0% … 25%
		64	25%
		65–127	25% … 50%
		128	50%
		129–191	50% … 75%
		192	75%
		193–254	75% … 100%
		255	100%
8	Dimmer 1	0	Closed
		1–254	Closed … Open
		255	Open
9	Shutter	0–9	Shutter: Open
		10–99	Strobe (1–15 Hz)
		100–109	Shutter: Open
		110–179	Lightning (1–15 Hz)
		180–189	Shutter: Open
		190–255	Random Strobe (1–15 Hz)
10	Zoom	0	Narrow
		1–127	Narrow … Mid
		128	Mid
		129–254	Mid … Wide
		255	Wide
11	Red 2	0–255	
12	Green 2	0–255	
13	Blue 2	0–255	
14	Color Macro		Ring Color Presets
		0–9	Open

CH	Function	DMX	Description
14	Color Macro (continued)	10–14	Red
		15–19	Green
		20–24	Blue
		25–29	Yellow
		30–34	Magenta
		35–39	Cyan
		40–44	White
		45–49	Violet Blue
		50–54	Light Blue
		55–59	Wine Red
		60–64	May Green
		65–69	Reseda Green
		70–74	Lilac Blue
		75–79	Moss Green
		80–84	Signal Violet
		85–89	Lilac Red
		90–94	Purple Red
		95–99	Green Brown
		100–104	Pale Green
		105–109	Ruby Red
		110–114	Flame Red
		115–119	Red Orange
		120–124	Rose
		125–129	Honey Yellow
		130–134	Light Pin
		135–139	Deep Orange
		140–144	Lemon
		145–149	Golden Yellow
		150–154	Pastel Orange
		155–159	Cream
		160–164	Melon Yellow
		165–169	Luminous Orange
		170–174	Luminous Yellow
		175–179	Open
		180–248	FX
		249–255	Open
15	Color Macro 2	0–9	Open
		10–23	FX 1
		24–37	FX 2
		38–51	FX 3
		52–65	FX 4
		66–79	FX 5


CH	Function	DMX	Description
15	Color Macro 2 (continued)	80–93	FX 6
		94–107	FX 7
		108–121	FX 8
		122–135	FX 9
		136–149	FX 10
		150–163	FX 11
		164–177	FX 12
		178–191	FX 13
		192–205	FX 14
		206–219	FX 15
		220–233	FX 16
		234–247	FX 17
		248–255	Closed
16	Color Macro 2 Speed		Color Macro 2 Rate
		0	Slow
		1–254	Slow ... Fast
		255	Fast
17	Dimmer 2	0	Closed
		1–254	Closed ... Open
		255	Open
18	Control	0–10	No Function
		11–20	P/T Blackout On
		21–30	P/T Blackout Off
		31–40	Pan Invert
		41–50	Tilt Invert
		51–60	P/T Invert Off
		61–70	Live
		71–80	Studio
		81–90	Power
		91–100	Reserved
		101–110	Dimmer Off
		111–120	Dimmer Mode
		121–150	Reserved
		151–160	1200Hz
		161–170	2400Hz
		171–180	4000Hz
		181–190	6000Hz
		191–200	25000
		201–210	Reset All
		211–220	P/T Reset
		221–230	Zoom Reset
		231–255	Reserved

Mode HSIC

16-bit parameters use two channels, coarse and fine: value = 256 × coarse value + fine value.

If the device receives DMX in this mode but gives no light, check these channels: CH 6 Dimmer 1 above 0; CH 11 Shutter at 0–9, 100–109 or 180–189 “Open”; CH 19 Dimmer 2 above 0. The GDTF file gives these values for a console's Highlight function: CH 6 Dimmer 1 255, CH 10 CTO 0, CH 11 Shutter 0.

Channel functions at a glance



CH	Function	DMX	Description
1	Pan	0	Home
		0–255	Pan 1
2	Pan Fine	0–255	Fine adjustment of CH 1
3	Tilt	0–127	Tilt 1
		127	Home
		128–255	Tilt 1
4	Tilt Fine	0–255	Fine adjustment of CH 3
5	Speed Pan/Tilt		Same as CH 3 in the mode “SSP” (p. 10)
6	Dimmer 1		Same as CH 8 in the mode “SSP” (p. 11)
7	Hue	0–255	
8	Hue Fine	0–255	Fine adjustment of CH 7
9	Saturation	0–255	
10	CTO	0–9	Open
		10–24	1800K
		25–39	2200K
		40–54	2700K
		55–69	3000K
		70–84	3200K
		85–99	4000K
		100–114	4500K
		115–129	5000K
		130–144	5600K
		145–159	6000K


CH	Function	DMX	Description
10	CTO (continued)	160–174	6500K
		175–189	7000K
		190–204	8000K
		205–255	10000K
11	Shutter		Same as CH 9 in the mode “SSP” (p. 11)
12	Zoom		Same as CH 10 in the mode “SSP” (p. 11)
13	Red	0	0%
		1–63	0% … 25%
		64	25%
		65–127	25% … 50%
		128	50%
		129–191	50% … 75%
		192	75%
		193–254	75% … 100%
		255	100%
14	Green	0	0%
		1–63	0% … 25%
		64	25%
		65–127	25% … 50%
		128	50%
		129–191	50% … 75%
		192	75%
		193–254	75% … 100%
		255	100%
15	Blue	0	0%
		1–63	0% … 25%
		64	25%
		65–127	25% … 50%
		128	50%
		129–191	50% … 75%
		192	75%
		193–254	75% … 100%
		255	100%
16	Color Macro		Same as CH 14 in the mode “SSP” (p. 11)
17	Color Macro 2		Same as CH 15 in the mode “SSP” (p. 12)
18	Color Macro 2 Speed	0	Slow
		1–254	Slow … Fast
		255	Fast
19	Dimmer 2		Same as CH 17 in the mode “SSP” (p. 13)
20	Control		Same as CH 18 in the mode “SSP” (p. 13)

Mode TR16

16-bit parameters use two channels, coarse and fine: value = 256 × coarse value + fine value.

If the device receives DMX in this mode but gives no light, check these channels: CH 14 Dimmer 1 above 0; CH 16 Shutter at 0–9, 100–109 or 180–189 “Open”; CH 28 Dimmer 2 above 0. The GDTF file gives these values for a console's Highlight function: CH 6 Red 1 255, CH 8 Green 1 255, CH 10 Blue 1 255, CH 12 White 0, CH 14 Dimmer 1 255, CH 16 Shutter 0, CH 17 Color Macro 1 0.

Channel functions at a glance



CH	Function	DMX	Description
1	Pan	0–127	Pan 1
		127	Home
		127–255	Pan 1
2	Pan Fine	0–255	Fine adjustment of CH 1
3	Tilt	0–127	Tilt 1
		127	Home
		127–255	Tilt 1
4	Tilt Fine	0–255	Fine adjustment of CH 3
5	Speed Pan/Tilt		Same as CH 3 in the mode “SSP” (p. 10)
6	Red 1	0–64	0% ... 25%
		64–128	25% ... 50%
		128–192	50% ... 75%
		192–255	75% ... 100%
		255	100%
7	Red 1 Fine	0–255	Fine adjustment of CH 6
8	Green 1	0–64	0% ... 25%
		64–128	25% ... 50%
		128–192	50% ... 75%

CH	Function	DMX	Description
8	Green 1 (continued)	192–255	75% ... 100%
		255	100%
9	Green 1 Fine	0–255	Fine adjustment of CH 8
10	Blue 1	0–64	0% ... 25%
		64–128	25% ... 50%
		128–192	50% ... 75%
		192–255	75% ... 100%
		255	100%
11	Blue 1 Fine	0–255	Fine adjustment of CH 10
12	White		Color Add White
		0–64	0% ... 25%
		64–128	25% ... 50%
		128–192	50% ... 75%
		192–255	75% ... 100%
		255	100%
13	White Fine	0–255	Fine adjustment of CH 12
14	Dimmer 1	0–255	Closed ... Open
		255	Open
15	Dimmer 1 Fine	0–255	Fine adjustment of CH 14
16	Shutter		Same as CH 9 in the mode “SSP” (p. 11)
17	Color Macro 1	0–10	Open
		11–170	RGB Blends
		171–195	All On
		196–199	1800K
		200–203	2200K
		204–207	2700K
		208–211	3000K
		212–215	3200K
		216–219	3500K
		220–223	4000K
		224–227	4200K
		228–231	4500K
		232–235	5600K
		236–239	6000K
		240–243	6500K
		244–247	7200K
		248–255	8000K
18	Pixel Mode		Static Pixel Effects
		0–9	No Function
		10–13	1
		14–17	2
		18–21	3

CH	Function	DMX	Description
18	Pixel Mode (continued)	22–25	4
		26–29	5
		30–33	6
		34–37	7
		38–41	8
		42–45	9
		46–49	10
		50–53	11
		54–57	12
		58–61	13
		62–65	14
		66–69	15
		70–73	16
		74–77	17
		78–81	18
		82–85	19
		86–89	1-2
		90–93	3-4
		94–97	5-6
		98–101	7-8
		102–105	9-10
		106–109	11-12
		110–113	13-14
		114–117	15-16
		118–121	17-18
		122–125	19-1
		126–129	1-2-3
		130–133	1-4-5
		134–137	1-6-7
		138–141	2-8-9
		142–145	3-10-11
		146–149	4-12-13
		150–153	5-14-16
		154–157	6-16-17
		158–161	7-18-19
		162–165	1-2-3-4
		166–169	1-5-6-7
		170–173	8-9-10-11
		174–177	12-13-14-15
		178–181	16-17-18-19
		182–185	2-3-4-5-6-7
		186–189	1-4-5-6-7

CH	Function	DMX	Description
18	Pixel Mode (continued)	190–193	8-9-10-11-12
		194–197	13-14-15-16-17
		198–201	18-19-8-9-10
		202–205	1-2-3-4-6-7
		206–209	8-9-10-11-12-13
		210–213	14-15-16-17-18-19
		214–217	1-2-3-4-5-6-7
		218–221	8-9-10-11-12-13-14-15-16-17-18-19
		222–225	1-2-3-4-8-9-10-11-12-13
		226–229	1-5-6-7-14-15-16-17-18-19
		230–233	1-2-3-6-7-8-9-10-17-18-19
		234–237	1-3-4-5-6-11-12-13-14-15-16
		238–241	1-2-3-4-5-6-7-8-10-12-14-16-18
		242–245	1-2-3-4-5-6-7-9-11-13-15-17-19
		246–249	1-2-4-6-8-10-12-14-16-18
		250–253	1-3-5-7-9-11-13-15-17-19
		254–255	Null
19	Effects	0–9	Open
		10–13	FX 1
		14–17	FX 2
		18–21	FX 3
		22–25	FX 4
		26–29	FX 5
		30–33	FX 6
		34–37	FX 7
		38–41	FX 8
		42–45	FX 9
		46–49	FX 10
		50–53	FX 11
		54–57	FX 12
		58–61	FX 13
		62–65	FX 14
		66–69	FX 15
		70–73	FX 16
		74–77	FX 17
		78–81	FX 18
		82–85	FX 19
		86–89	FX 20
		90–93	FX 21
		94–97	FX 22
		98–101	FX 23
		102–105	FX 24

CH	Function	DMX	Description
19	Effects (continued)	106–109	FX 25
		110–113	FX 26
		114–117	FX 27
		118–121	FX 28
		122–125	FX 29
		126–129	FX 30
		130–133	FX 31
		134–137	FX 32
		138–141	FX 33
		142–145	FX 34
		146–149	FX 35
		150–153	FX 36
		154–157	FX 37
		158–161	FX 38
		162–165	FX 39
		166–169	FX 40
		170–173	FX 41
		174–177	FX 42
		178–181	FX 43
		182–185	FX 44
		186–187	FX 45
		188	FX 45 … FX 46
		189–192	FX 46
		193–196	FX 47
		197–201	FX 48
		202–205	FX 49
		206–209	FX 50
		210–215	FX 51
		216–221	FX 52
		222–227	FX 53
		228–230	FX 54
		231–233	FX 55
		234–236	FX 56
		237–239	FX 57
		240–242	FX 58
		243–245	FX 59
		246–248	FX 60
		249–251	FX 61
		252–254	FX 62
		255	FX 63
20	Effects Speed	0	Slow
		1–254	Slow … Fast

CH	Function	DMX	Description
20	Effects Speed (continued)	255	Fast
21	Zoom		Same as CH 10 in the mode “SSP” (p. 11)
22	Red 2	0–255	
23	Green 2	0–255	
24	Blue 2	0–255	
25	Color Macro 2		Ring Color Presets
		0–9	Open
		10–14	Red
		15–19	Green
		20–24	Blue
		25–29	Yellow
		30–34	Magenta
		35–39	Cyan
		40–44	White
		45–49	Violet Blue
		50–54	Light Blue
		55–59	Wine Red
		60–64	May Green
		65–69	Reseda Green
		70–74	Lilac Blue
		75–79	Moss Green
		80–84	Signal Violet
		85–89	Lilac Red
		90–94	Purple Red
		95–99	Green Brown
		100–104	Pale Green
		105–109	Ruby Red
		110–114	Flame Red
		115–119	Red Orange
		120–124	Rose
		125–129	Honey Yellow
		130–134	Light Pin
		135–139	Deep Orange
		140–144	Lemon
		145–149	Golden Yellow
		150–154	Pastel Orange
		155–159	Cream
		160–164	Melon Yellow
		165–169	Luminous Orange
		170–174	Luminous Yellow
		175–179	Open
		180–248	FX


CH	Function	DMX	Description
25	Color Macro 2 (continued)	249–255	Open
26	Color Macro 3	0–9	Open
		10–23	FX 1
		24–37	FX 2
		38–51	FX 3
		52–65	FX 4
		66–79	FX 5
		80–93	FX 6
		94–107	FX 7
		108–121	FX 8
		122–135	FX 9
		136–149	FX 10
		150–163	FX 11
		164–177	FX 12
		178–191	FX 13
		192–205	FX 14
		206–219	FX 15
		220–233	FX 16
		234–247	FX 17
		248–255	Closed
27	Color Macro 2 Speed		Same as CH 16 in the mode “SSP” (p. 13)
28	Dimmer 2		Same as CH 17 in the mode “SSP” (p. 13)
29	Control		Same as CH 18 in the mode “SSP” (p. 13)

Mode CMY

16-bit parameters use two channels, coarse and fine: value = 256 × coarse value + fine value.

If the device receives DMX in this mode but gives no light, check these channels: CH 9 Dimmer 1 above 0; CH 10 Shutter at 0–9, 100–109 or 180–189 “Open”; CH 22 Dimmer 2 above 0. The GDTF file gives these values for a console's Highlight function: CH 6 Cyan 0, CH 7 Magenta 0, CH 8 Yellow 0, CH 9 Dimmer 1 255, CH 10 Shutter 0, CH 11 Color Macro 1 0.

Channel functions at a glance




CH	Function	DMX	Description
1	Pan		Same as CH 1 in the mode “TR16” (p. 16)
2	Pan Fine	0–255	Fine adjustment of CH 1
3	Tilt		Same as CH 3 in the mode “TR16” (p. 16)
4	Tilt Fine	0–255	Fine adjustment of CH 3
5	Speed Pan/Tilt		Same as CH 3 in the mode “SSP” (p. 10)
6	Cyan	0	0%
		1–63	0% ... 25%
		64	25%
		65–127	25% ... 50%
		128	50%
		129–191	50% ... 75%
		192	75%
		193–254	75% ... 100%
		255	100%
7	Magenta	0	0%
		1–63	0% ... 25%
		64	25%
		65–127	25% ... 50%
		128	50%

CH	Function	DMX	Description
7	Magenta (continued)	129–191	50% … 75%
		192	75%
		193–254	75% … 100%
		255	100%
8	Yellow	0	0%
		1–63	0% … 25%
		64	25%
		65–127	25% … 50%
		128	50%
		129–191	50% … 75%
		192	75%
		193–254	75% … 100%
		255	100%
9	Dimmer 1		Same as CH 8 in the mode “SSP” (p. 11)
10	Shutter		Same as CH 9 in the mode “SSP” (p. 11)
11	Color Macro 1		Same as CH 17 in the mode “TR16” (p. 17)
12	Pixel Mode		Same as CH 18 in the mode “TR16” (p. 17)
13	Effects		Same as CH 19 in the mode “TR16” (p. 19)
14	Effects Speed		Same as CH 20 in the mode “TR16” (p. 20)
15	Zoom		Same as CH 10 in the mode “SSP” (p. 11)
16	Red	0–255	
17	Green	0–255	
18	Blue	0–255	
19	Color Macro 2		Same as CH 25 in the mode “TR16” (p. 21)
20	Color Macro 3		Same as CH 26 in the mode “TR16” (p. 22)
21	Color Macro 2 Speed		Same as CH 16 in the mode “SSP” (p. 13)
22	Dimmer 2		Same as CH 17 in the mode “SSP” (p. 13)
23	Control		Same as CH 18 in the mode “SSP” (p. 13)

Mode Tour

If the device receives DMX in this mode but gives no light, check these channels: CH 8 Dimmer 1 above 0; CH 9 Shutter at 0–9, 100–109 or 180–189 “Open”; CH 21 Dimmer 2 above 0. The GDTF file gives these values for a console's Highlight function: CH 4 Red 1 255, CH 5 Green 1 255, CH 6 Blue 1 255, CH 7 White 0, CH 8 Dimmer 1 255, CH 9 Shutter 0, CH 10 Color Macro 1 0.

Channel functions at a glance



CH	Function	DMX	Description
1	Pan		Same as CH 1 in the mode “SSP” (p. 10)
2	Tilt		Same as CH 2 in the mode “SSP” (p. 10)
3	Speed Pan/Tilt		Same as CH 3 in the mode “SSP” (p. 10)
4	Red 1		Same as CH 4 in the mode “SSP” (p. 10)
5	Green 1		Same as CH 5 in the mode “SSP” (p. 10)
6	Blue 1		Same as CH 6 in the mode “SSP” (p. 11)
7	White		Same as CH 7 in the mode “SSP” (p. 11)
8	Dimmer 1		Same as CH 8 in the mode “SSP” (p. 11)
9	Shutter		Same as CH 9 in the mode “SSP” (p. 11)
10	Color Macro 1		Same as CH 17 in the mode “TR16” (p. 17)
11	Pixel Mode		Same as CH 18 in the mode “TR16” (p. 17)
12	Effects		Same as CH 19 in the mode “TR16” (p. 19)
13	Effects Speed		Same as CH 20 in the mode “TR16” (p. 20)
14	Zoom		Same as CH 10 in the mode “SSP” (p. 11)
15	Red 2	0–255	
16	Green 2	0–255	
17	Blue 2	0–255	
18	Color Macro 2		Same as CH 25 in the mode “TR16” (p. 21)
19	Color Macro 3		Same as CH 26 in the mode “TR16” (p. 22)


CH	Function	DMX	Description
20	Color Macro 2 Speed		Same as CH 16 in the mode “SSP” (p. 13)
21	Dimmer 2		Same as CH 17 in the mode “SSP” (p. 13)
22	Control		Same as CH 18 in the mode “SSP” (p. 13)

Mode Pixel

16-bit parameters use two channels, coarse and fine: value = 256 × coarse value + fine value.

If the device receives DMX in this mode but gives no light, check these channels: CH 13 Dimmer 1 above 0; CH 15 Dimmer 2 above 0; CH 16 Shutter at 0–9, 100–109 or 180–189 “Open”. The GDTF file gives these values for a console's Highlight function: CH 15 Dimmer 2 255, CH 16 Shutter 0, CH 17 Red 255 (the same in each of the 19 cells), CH 18 Green 255 (the same in each of the 19 cells), CH 19 Blue 255 (the same in each of the 19 cells), CH 20 White 0 (the same in each of the 19 cells).

Channel functions at a glance



CH	Function	DMX	Description
1	Pan		Same as CH 1 in the mode “TR16” (p. 16)
2	Pan Fine	0–255	Fine adjustment of CH 1
3	Tilt		Same as CH 3 in the mode “TR16” (p. 16)
4	Tilt Fine	0–255	Fine adjustment of CH 3
5	Speed Pan/Tilt		Same as CH 3 in the mode “SSP” (p. 10)
6	Zoom		Same as CH 10 in the mode “SSP” (p. 11)
7	Red 1	0–255	
8	Green 1	0–255	
9	Blue 1	0–255	
10	Color Macro		Same as CH 14 in the mode “SSP” (p. 11)
11	Color Macro 2		Same as CH 15 in the mode “SSP” (p. 12)
12	Color Macro 2 Speed		Same as CH 16 in the mode “SSP” (p. 13)
13	Dimmer 1		Same as CH 8 in the mode “SSP” (p. 11)
14	Control		Same as CH 18 in the mode “SSP” (p. 13)
15	Dimmer 2		Same as CH 17 in the mode “SSP” (p. 13)
16	Shutter		Same as CH 9 in the mode “SSP” (p. 11)
17	Red 2	0	0%
		1–63	0% ... 25%
		64	25%
		65–127	25% ... 50%

CH	Function	DMX	Description
17	Red 2 (continued)	128	50%
		129–191	50% … 75%
		192	75%
		193–254	75% … 100%
		255	100%
18	Green 2	0	0%
		1–63	0% … 25%
		64	25%
		65–127	25% … 50%
		128	50%
		129–191	50% … 75%
		192	75%
		193–254	75% … 100%
		255	100%
19	Blue 2	0	0%
		1–63	0% … 25%
		64	25%
		65–127	25% … 50%
		128	50%
		129–191	50% … 75%
		192	75%
		193–254	75% … 100%
		255	100%
20	White 1	0	0%
		1–63	0% … 25%
		64	25%
		65–127	25% … 50%
		128	50%
		129–191	50% … 75%
		192	75%
		193–254	75% … 100%
		255	100%

CH 17–92: 19 cells of 4 channels each. Every cell works as cell 1 in the table above (CH 17–20); the table below gives each cell's channel numbers.

Cell	Red	Green	Blue	White	Cell	Red	Green	Blue	White
1	17	18	19	20	2	21	22	23	24
3	25	26	27	28	4	29	30	31	32
5	33	34	35	36	6	37	38	39	40
7	41	42	43	44	8	45	46	47	48
9	49	50	51	52	10	53	54	55	56
11	57	58	59	60	12	61	62	63	64
13	65	66	67	68	14	69	70	71	72

Cell	Red	Green	Blue	White	Cell	Red	Green	Blue	White
15	73	74	75	76	16	77	78	79	80
17	81	82	83	84	18	85	86	87	88
19	89	90	91	92					


10 Technical specifications

Parameter	Value
Light source	LED
Zoom	6–45°
Pan	540°
Tilt	220°
Weight	23 kg
Operating temperature	-20 to 45 °C

Speeds and ranges

Parameter	Value
Color temperature range	1800–10000 K
Strobe frequency	1–15 Hz

Spot diameter



Distance	Ø 6°	Ø 45°
2 m	0.21 m	1.7 m
4 m	0.42 m	3.3 m
6 m	0.63 m	5 m
8 m	0.84 m	6.6 m
10 m	1 m	8.3 m
15 m	1.6 m	12.4 m

Spot diameter square to the beam axis, calculated from the beam angle.

11 Maintenance and cleaning

- Before cleaning and maintenance, switch the device off, disconnect it from the power supply and let it cool down.
- Clean the housing with a soft, dry or slightly damp cloth. Do not use solvents, abrasive cleaners or pressure washers, and make sure no liquid gets into the device.
- Clean optical parts (lenses, front glass), if the device has any, with a soft lint-free cloth and a cleaner intended for optics or glass.
- Regularly inspect the housing, cables, connectors and fixings. Have damaged parts replaced by a service center.
- How often to clean depends on the environment; dust, smoke and fog make the device dirty much faster.

12 Troubleshooting

Problem	Remedy
The device does not switch on	Check the supply voltage, the cables and the fuse, if the device has one.
The device does not respond to DMX	Check the start address, the selected DMX mode and whether it matches the profile in the controller, the cable connection to DMX IN, and the controller output (universe).
The device behaves erratically or flickers	Check the terminator at the end of the line, the condition and wiring of the cables (shield on pin 1 only), the number of devices on the line (32 at most), and that the line is not split without a splitter.
Only some devices on the line respond	Check the cable and connectors between the last working and the first non-working device, and make sure all devices on the line are switched on.
Devices respond to the wrong channels or affect each other	Check that the addresses do not overlap and that the DMX mode on the devices matches the patch in the controller.
The device or the connected load does not light up although it receives DMX	Check the values of the dimmer, shutter and strobe channels against the DMX channel table. For the DMX modes for which the sources state it, the chapter DMX channels gives under the mode's heading which channels must be open.
Movement is reversed	Check whether Pan/Tilt inversion is enabled in the device menu or in the controller.
Moving parts do not reach the correct position after power-on or transport	Switch the device off and on again to reset the position, and make sure the transport lock, if any, is released. If this does not help, contact a service center.
Movement is jerky	Check the value of the Pan/Tilt speed channel, if the device has one, and the stability of the DMX signal.

13 Disposal

The crossed-out wheeled bin symbol on the product, in the manual or on the packaging means that the product must not be disposed of with unsorted household waste at the end of its life.

Take the end-of-life equipment to a collection point, for example a municipal collection site or a retailer. Proper disposal enables materials to be recycled and helps prevent possible negative effects on the environment and human health.

Follow the regulations applicable in your country; in the Czech Republic, take-back is governed by Act No. 542/2020 Coll., on End-of-Life Products.

Recycle the packaging materials according to their type.