DMX REFERENCE

Hero Wash 715 HEX LED

Varytec



Manufacturer	Varytec
GDTF file	Varytec_Hero_Wash_715_HEX_LED_145065.gdtf
GDTF revision	DMX completed · 2026-06-01
Generated	2026-11-24

Contents

1 About this manual 2
2 Quick reference 3
3 Safety instructions 4
4 Product description 5
5 Installation 6
6 Connections 6
7 Operation 7
8 Functions at a glance 7
9 DMX channels 9
Mode 7-Channel 9
Mode 16-Channel 11
10 Technical specifications 13
11 Maintenance and cleaning 13
12 Troubleshooting 14
13 Disposal 14

1 About this manual

This document describes the Hero Wash 715 HEX LED by Varytec. It was compiled from the GDTF file Varytec_Hero_Wash_715_HEX_LED_145065.gdtf from the GDTF-Share library.

File revision: “DMX completed”.

The DMX modes, the channel functions and the technical data are given as the GDTF file states them. Installation, operation from the device's control panel, service and safety instructions are described in the manufacturer's original user manual, which takes precedence over this document.

This document was not issued or endorsed by Varytec; product names and trademarks belong to their owners.

Safety notices are marked with signal words according to the severity of the hazard: DANGER – an imminent hazard that will result in death or serious injury; WARNING – a potential hazard that could result in death or serious injury; CAUTION – a potential hazard that could result in minor injury or property damage; NOTE – additional information for correct and safe use.

> **NOTE** This product is designed for stage and effect lighting. It is not suitable for household room illumination.

2 Quick reference

Parameter	Value
Power consumption	850 W
Weight	3.8 kg

DMX modes

Mode	Channels	Units in one universe	First start addresses
7-Channel	7	73	1, 8, 15, 22, ...
16-Channel	16	32	1, 17, 33, 49, ...

No light? Check these channels

- 7-Channel: CH 4 Dimmer above 0; CH 5 Shutter at 0–9 or 251–255 “Open”
- 16-Channel: CH 6 Dimmer above 0; CH 7 Shutter at 0–9 or 251–255 “Open”


Read the manual before use


Risk of electric shock


Do not stare into the light


Indoor use only

3 Safety instructions


Read the manual before use


Risk of electric shock


Do not stare into the light


Indoor use only

⚠ WARNING

- This device is intended for professional use. Installation, connection, setup and maintenance must be carried out only by suitably qualified persons who have read this manual.
- Use the device only for its intended purpose and as described in this manual.
- Do not open the housing and do not modify or tamper with the device. Refer all repairs to an authorized service center.
- Do not use the device if its housing, power or data cable, or a connector is damaged, if the device has been dropped, or if liquid or a foreign object has entered it. In such a case, have it checked by a service center.
- Disconnect the device from the power supply before cleaning, maintenance or any work on the connections.
- After moving the device from a cold to a warm environment, let it reach room temperature before switching it on to prevent condensation inside.
- The device is not a toy; keep it out of the reach of children.

⚠ WARNING

- Connect the device only to a properly installed mains outlet with a protective earth (ground) contact. The outlet or other means of disconnection must remain easily accessible.
- Power supply: 100–240 V, 50/60 Hz. Before connecting, make sure that the mains voltage matches this value and the value on the rating plate of the device.
- Do not connect the device to a dimmer or to a dimmed circuit.
- Use only the original power cable or a cable with identical ratings. Protect the cable from damage, do not run it over sharp edges, and never unplug it by pulling on the cable.
- When connecting several devices to one circuit, do not exceed its permitted load.
- Do not touch the device with wet hands.

⚠ WARNING

- This device is designed for indoor use only. Protect it from rain, splashing water, moisture and dust, and do not place containers with liquids on it.
- Do not operate the device in high humidity, near water, or where condensation can form on it.

⚠ CAUTION

- This device emits intense light. Do not look directly into the light source or the beam at close range; doing so may damage your eyes.
- Do not aim the beam at the eyes of people or animals at close range, and do not view the light source through optical instruments (binoculars, camera lenses).
- Do not aim the beam at flammable or heat-sensitive materials at close range.

⚠ WARNING

- This device emits ultraviolet (UV) radiation, which can harm the eyes and skin.
- Do not look directly into the light source and avoid prolonged exposure of the eyes and skin at close range. Install the device so that people are not exposed at close range.
- People with increased sensitivity to light, including those taking medication that increases this sensitivity, should avoid UV exposure.

⚠ CAUTION

- Strobe and fast flashing light effects can trigger epileptic seizures in susceptible people (photosensitive epilepsy) and can cause nausea or disorientation.
- Inform the audience and performers in advance that strobe effects will be used, for example with a notice at the entrance, and do not use them longer than necessary.

⚠ WARNING

- The moving parts of the device (for example the head or arms) can move quickly and unexpectedly at any time – after power-on, during a reset, or on a command from the controller.
- Keep yourself and any objects out of the range of movement. While the device is switched on, do not touch the moving parts, move them by hand, or obstruct their movement; this can cause injury (pinching) and damage the drive.
- Do not carry the device by its moving parts. If the device has a transport lock, engage it before transport and release it before switching on.

4 Product description

Description in the GDTF file

- LED Moving Head Wash
- 7 x 15W RGBAW UV leds
- 7/16 DMX channels
- 16-Bit pan / tilt 540° / 190°
- Electronic shutter (Strobo) 0 - 20 Hz
- Fan-cooled
- Power Twist connectors

“Note: In 16-channel mode -Color Macros (ch15) require Dimmer (ch6) to be between 1-255. - Preprogrammed automatic shows (ch16) also require Color Macros (ch15) to be between 10-255.”

5 Installation

⚠ **WARNING**

- Rigging must be carried out only by qualified persons in accordance with applicable regulations, in particular those for work at height.
- The supporting structure and fixings must safely carry the weight of all suspended devices; verify their load capacity in advance.
- Weight of the device: 3.8 kg.
- Use suitable mounting hardware (for example truss clamps) and tighten all screw connections properly.
- Always secure the suspended device against falling with a safety cable of adequate load capacity, routed through a fixed point of the device and around the supporting structure.
- During installation and removal, keep people out of the area below the work position.
- Regularly inspect the fixings and the safety cable for damage, corrosion and loosening.

6 Connections

- Use shielded cable designed for DMX512 with an impedance of 110 Ω. Ordinary microphone cable is not suitable for DMX, especially over longer distances.
- Connect the devices in a daisy chain: connect the DMX OUT of one device to the DMX IN of the next. Do not split the line with Y-cables or wire it in a star; the line may be split only with a DMX splitter.
- Connect the shield to pin 1 only. Do not connect the shield (ground) to the metal shell of the connector; this can cause short circuits or erratic behavior.
- XLR pin assignment: pin 1 – shield (ground), pin 2 – Data- (Data Complement), pin 3 – Data+ (Data True). On 5-pin connectors, pins 4 and 5 are not connected; a 5-pin connector can be connected to a 3-pin one with a cable adapter.
- Terminate the end of the line (for impedance matching): plug an XLR connector with a 120 Ω, ¼ W resistor between pins 2 and 3 into the DMX OUT of the last device. This reduces the risk of erratic behavior.
- Connect no more than 32 devices to one DMX line. For more devices or longer runs, use a DMX splitter or booster.

DMX line



Mode 16-Channel: every unit occupies 16 channels from its address. At most 32 units on one line; for more units or longer runs use a DMX splitter. A 120 Ω terminator closes the last DMX OUT.

7 Operation

Setting the DMX address

- The device occupies as many consecutive channels in the DMX universe as the selected DMX mode uses, starting at the set start address.
- Number of channels occupied in the DMX mode “16-Channel”: 16.
- Choose start addresses so that the channels of individual devices do not overlap and the last occupied channel does not exceed 512. Devices with the same start address and mode respond identically.
- For several devices in a row in the DMX mode “16-Channel”, you can use, for example, the start addresses 1, 17, 33, 49.
- The DMX mode set on the device must match the fixture profile (personality) used in the controller.

8 Functions at a glance

Functions in each DMX mode

	7-Channel 7 channels	16-Channel 16 channels
Pan / Tilt	1, 2	1, 3
Dimmer	4	6
Shutter / strobe	5	7
Color mixing		8–13
Effects / macros	6	15 *

* The function works only when another channel switches it on; see the DMX table.

LED colors and the colors they mix



LED	x	y
Red	0.729	0.265
Green	0.066	0.826
Blue	0.134	0.046
Amber	0.561	0.367
White	0.313	0.325
UV	0.407	0.295

The shaded area holds the colors the LEDs can mix; the dots are the LED colors the GDTF file states.

9 DMX channels

Units in one DMX universe



Start addresses of 20 units in the mode “16-Channel”

Unit	Start address	Unit	Start address	Unit	Start address	Unit	Start address
1	1	6	81	11	161	16	241
2	17	7	97	12	177	17	257
3	33	8	113	13	193	18	273
4	49	9	129	14	209	19	289
5	65	10	145	15	225	20	305

Mode 7-Channel

If the device receives DMX in this mode but gives no light, check these channels: CH 4 Dimmer above 0; CH 5 Shutter at 0–9 or 251–255 “Open”.

Channel functions at a glance



CH	Function	DMX	Description
1	Pan	0–255	Rotation
2	Tilt	0–255	Inclination
3	Speed Pan/Tilt		Movement Speed
		0–255	Speed
4	Dimmer	0–255	
5	Shutter	0–9	Open
		10–250	Strobo speed 0-20 Hz
		251–255	Open
6	Color Macro	0–10	No function
		11–20	Red + 50 % white

CH	Function	DMX	Description
6	Color Macro (continued)	21–30	Red
		31–40	Red + Amber
		41–50	Amber
		51–60	Red + 75% Green + Amber
		61–70	Red + Green = Yellow
		71–80	Green
		81–90	Green + White = Light Green
		91–100	Green + UV = Green UV
		101–110	Green + Blue = Cyan
		111–120	Blue + UV = Blue UV
		121–130	Blue
		131–140	UV
		141–150	50% Red + UV = Red UV
		151–160	Amber + UV = Amber UV
		161–170	Red + Amber + UV
		171–180	Red + UV = Red UV
		181–190	Red + White + Amber
		191–200	Amber + White = Light Amber
		201–210	White
		211–220	Blue + White = Light Blue
		221–230	R + G + B + A + W + UV
		231–240	Color Sequence (Speed)
		241–255	Color Fade (Speed)
7	Position Effect		Automatic show
		0–10	Preprogrammed automatic show 1
		11–20	Preprogrammed automatic show 2
		21–30	Preprogrammed automatic show 3
		31–40	Preprogrammed automatic show 4
		41–50	Preprogrammed automatic show 5
		51–60	Preprogrammed automatic show 6
		61–70	Preprogrammed automatic show 7
		71–80	Preprogrammed automatic show 8
		81–230	Sound control (Sensitivity)
		231–240	Reset (if transmitted for >3s)
		241–255	No function

Mode 16-Channel

If the device receives DMX in this mode but gives no light, check these channels: CH 6 Dimmer above 0; CH 7 Shutter at 0–9 or 251–255 “Open”.

Channel functions at a glance



CH	Function	DMX	Description
1	Pan	0–255	Rotation
2	Pan Fine		Pain (Fine)
		0–255	Rotation (Fine)
3	Tilt	0–255	Inclination
4	Tilt Fine		Tilt (Fine)
		0–255	Inclination (Fine)
5	Speed Pan/Tilt		Movement Speed
		0–255	Movement Speed
6	Dimmer	0–255	
7	Shutter		Same as CH 5 in the mode “7-Channel” (p. 9)
8	Red	0–255	Red Intensity
9	Green	0–255	Green Intensity
10	Blue	0–255	Blue Intensity
11	White	0–255	White Intensity
12	Amber	0–255	Amber Intensity
13	UV	0–255	UV Intensity
14	Color Control		Color Temperature
		0–255	Color Temperature
15	Color Macro		When CH 6 is 1–255:
		0–10	No function (No autoshow)

CH	Function	DMX	Description
15	Color Macro (continued)	11–20	Red + 50 % white
		21–30	Red
		31–40	Red + Amber
		41–50	Amber
		51–60	Red + 75% Green + Amber
		61–70	Red + Green = Yellow
		71–80	Green
		81–90	Green + White = Light Green
		91–100	Green + UV = Green UV
		101–110	Green + Blue = Cyan
		111–120	Blue + UV = Blue UV
		121–130	Blue
		131–140	UV
		141–150	50% Red + UV = Red UV
		151–160	Amber + UV = Amber UV
		161–170	Red + Amber + UV
		171–180	Red + UV = Red UV
		181–190	Red + White + Amber
		191–200	Amber + White = Light Amber
		201–210	White
		211–220	Blue + White = Light Blue
		221–230	R + G + B + A + W + UV
		231–240	Color Sequence (Speed)
		241–255	Color Fade (Speed)
16	Position Effect		When CH 15 is 10–255:
		0–10	Preprogrammed automatic show 1
		11–20	Preprogrammed automatic show 2
		21–30	Preprogrammed automatic show 3
		31–40	Preprogrammed automatic show 4
		41–50	Preprogrammed automatic show 5
		51–60	Preprogrammed automatic show 6
		61–70	Preprogrammed automatic show 7
		71–80	Preprogrammed automatic show 8
		81–230	Sound control (Sensitivity)
		231–240	Reset (if transmitted for >3s)
		241–255	No function

10 Technical specifications

Parameter	Value
Light	
Light source	LED
LED power	105 W
Luminous flux	1,000 lm
Color temperature	6,000 K
Color rendering index (CRI)	85
Optics	
Beam angle	25°
Control	
DMX connection	5-pin XLR IN/OUT, 3-pin XLR IN/OUT
RJ45 connectors	RJ45 IN
Electrical	
Power supply	100–240 V, 50/60 Hz
Power consumption	850 W
Power connectors	powerCON TRUE1 IN/OUT
Dimensions and construction	
Weight	3.8 kg
Operating environment	
Operating temperature	0 to 40 °C

Spot diameter



Distance	Ø 25°
2 m	0.89 m
4 m	1.8 m
6 m	2.7 m
8 m	3.5 m
10 m	4.4 m
15 m	6.7 m

Spot diameter square to the beam axis, calculated from the beam angle.

11 Maintenance and cleaning

- Before cleaning and maintenance, switch the device off, disconnect it from the power supply and let it cool down.
- Clean the housing with a soft, dry or slightly damp cloth. Do not use solvents, abrasive cleaners or pressure washers, and make sure no liquid gets into the device.
- Clean optical parts (lenses, front glass), if the device has any, with a soft lint-free cloth and a cleaner intended for optics or glass.

- Regularly inspect the housing, cables, connectors and fixings. Have damaged parts replaced by a service center.
- How often to clean depends on the environment; dust, smoke and fog make the device dirty much faster.

12 Troubleshooting

Problem	Remedy
The device does not switch on	Check the supply voltage, the cables and the fuse, if the device has one.
The device does not respond to DMX	Check the start address, the selected DMX mode and whether it matches the profile in the controller, the cable connection to DMX IN, and the controller output (universe).
The device behaves erratically or flickers	Check the terminator at the end of the line, the condition and wiring of the cables (shield on pin 1 only), the number of devices on the line (32 at most), and that the line is not split without a splitter.
Only some devices on the line respond	Check the cable and connectors between the last working and the first non-working device, and make sure all devices on the line are switched on.
Devices respond to the wrong channels or affect each other	Check that the addresses do not overlap and that the DMX mode on the devices matches the patch in the controller.
The device or the connected load does not light up although it receives DMX	Check the values of the dimmer, shutter and strobe channels against the DMX channel table. For the DMX modes for which the sources state it, the chapter DMX channels gives under the mode's heading which channels must be open.
Movement is reversed	Check whether Pan/Tilt inversion is enabled in the device menu or in the controller.
Moving parts do not reach the correct position after power-on or transport	Switch the device off and on again to reset the position, and make sure the transport lock, if any, is released. If this does not help, contact a service center.
Movement is jerky	Check the value of the Pan/Tilt speed channel, if the device has one, and the stability of the DMX signal.

13 Disposal

The crossed-out wheeled bin symbol on the product, in the manual or on the packaging means that the product must not be disposed of with unsorted household waste at the end of its life.

Take the end-of-life equipment to a collection point, for example a municipal collection site or a retailer. Proper disposal enables materials to be recycled and helps prevent possible negative effects on the environment and human health.

Follow the regulations applicable in your country; in the Czech Republic, take-back is governed by Act No. 542/2020 Coll., on End-of-Life Products.

Recycle the packaging materials according to their type.