DMX REFERENCE

sky beamAG

Beam 380W 19R Moving Head

sky beam 320



Manufacturer	sky beam 320
GDTF file	sky_beam_320_sky_beamAG_138348.gdtf
GDTF revision	sky beam AG · 2026-04-13
Generated	2026-11-24

Contents

1 About this manual 2
2 Quick reference 2
3 Safety instructions 3
4 Product description 4
5 Installation 5
6 Connections 5
7 Operation 6
8 Functions at a glance 6
9 DMX channels 7
Mode 1 8
10 Technical specifications 11
11 Maintenance and cleaning 11
12 Troubleshooting 12
13 Disposal 12

1 About this manual

This document describes the Beam 380W 19R Moving Head by sky beam 320. It was compiled from the GDTF file sky_beam_320_sky_beamAG_138348.gdtf from the GDTF-Share library.

File revision: “sky beam AG”.

The DMX modes, the channel functions and the technical data are given as the GDTF file states them. Installation, operation from the device's control panel, service and safety instructions are described in the manufacturer's original user manual, which takes precedence over this document.

This document was not issued or endorsed by sky beam 320; product names and trademarks belong to their owners.

Safety notices are marked with signal words according to the severity of the hazard: DANGER – an imminent hazard that will result in death or serious injury; WARNING – a potential hazard that could result in death or serious injury; CAUTION – a potential hazard that could result in minor injury or property damage; NOTE – additional information for correct and safe use.

> **NOTE** This product is designed for stage and effect lighting. It is not suitable for household room illumination.

2 Quick reference

Parameter	Value
Power consumption	850 W
Weight	20 kg

DMX modes

Mode	Channels	Units in one universe	First start addresses
Mode 1	16	32	1, 17, 33, 49, …

No light? Check these channels

- Mode 1: CH 3 Shutter at 104–107, 208–212 or 252–255 “Open”


Read the manual before use


Risk of electric shock


Do not stare into the light


Indoor use only

3 Safety instructions


Read the manual before use


Risk of electric shock


Do not stare into the light


Indoor use only

⚠ WARNING

- This device is intended for professional use. Installation, connection, setup and maintenance must be carried out only by suitably qualified persons who have read this manual.
- Use the device only for its intended purpose and as described in this manual.
- Do not open the housing and do not modify or tamper with the device. Refer all repairs to an authorized service center.
- Do not use the device if its housing, power or data cable, or a connector is damaged, if the device has been dropped, or if liquid or a foreign object has entered it. In such a case, have it checked by a service center.
- Disconnect the device from the power supply before cleaning, maintenance or any work on the connections.
- After moving the device from a cold to a warm environment, let it reach room temperature before switching it on to prevent condensation inside.
- The device is not a toy; keep it out of the reach of children.

⚠ WARNING

- Connect the device only to a properly installed mains outlet with a protective earth (ground) contact. The outlet or other means of disconnection must remain easily accessible.
- Power supply: 100–240 V, 50/60 Hz. Before connecting, make sure that the mains voltage matches this value and the value on the rating plate of the device.
- Do not connect the device to a dimmer or to a dimmed circuit.
- Use only the original power cable or a cable with identical ratings. Protect the cable from damage, do not run it over sharp edges, and never unplug it by pulling on the cable.
- When connecting several devices to one circuit, do not exceed its permitted load.
- Do not touch the device with wet hands.

⚠ WARNING

- This device is designed for indoor use only. Protect it from rain, splashing water, moisture and dust, and do not place containers with liquids on it.
- Do not operate the device in high humidity, near water, or where condensation can form on it.

⚠ CAUTION

- This device emits intense light. Do not look directly into the light source or the beam at close range; doing so may damage your eyes.
- Do not aim the beam at the eyes of people or animals at close range, and do not view the light source through optical instruments (binoculars, camera lenses).
- Do not aim the beam at flammable or heat-sensitive materials at close range.

> ⚠ **CAUTION**
>
> - Strobe and fast flashing light effects can trigger epileptic seizures in susceptible people (photosensitive epilepsy) and can cause nausea or disorientation.
> - Inform the audience and performers in advance that strobe effects will be used, for example with a notice at the entrance, and do not use them longer than necessary.


> ⚠ **WARNING**
>
> - The moving parts of the device (for example the head or arms) can move quickly and unexpectedly at any time – after power-on, during a reset, or on a command from the controller.
> - Keep yourself and any objects out of the range of movement. While the device is switched on, do not touch the moving parts, move them by hand, or obstruct their movement; this can cause injury (pinching) and damage the drive.
> - Do not carry the device by its moving parts. If the device has a transport lock, engage it before transport and release it before switching on.

4 Product description

Range of movement


Pan 1080°

top view



Tilt 540°

side view



5 Installation


⚠ WARNING

- Rigging must be carried out only by qualified persons in accordance with applicable regulations, in particular those for work at height.
- The supporting structure and fixings must safely carry the weight of all suspended devices; verify their load capacity in advance.
- Weight of the device: 20 kg.
- Use suitable mounting hardware (for example truss clamps) and tighten all screw connections properly.
- Always secure the suspended device against falling with a safety cable of adequate load capacity, routed through a fixed point of the device and around the supporting structure.
- During installation and removal, keep people out of the area below the work position.
- Regularly inspect the fixings and the safety cable for damage, corrosion and loosening.

6 Connections

- Use shielded cable designed for DMX512 with an impedance of 110 Ω. Ordinary microphone cable is not suitable for DMX, especially over longer distances.
- Connect the devices in a daisy chain: connect the DMX OUT of one device to the DMX IN of the next. Do not split the line with Y-cables or wire it in a star; the line may be split only with a DMX splitter.
- Connect the shield to pin 1 only. Do not connect the shield (ground) to the metal shell of the connector; this can cause short circuits or erratic behavior.
- XLR pin assignment: pin 1 – shield (ground), pin 2 – Data- (Data Complement), pin 3 – Data+ (Data True). On 5-pin connectors, pins 4 and 5 are not connected; a 5-pin connector can be connected to a 3-pin one with a cable adapter.
- Terminate the end of the line (for impedance matching): plug an XLR connector with a 120 Ω, ¼ W resistor between pins 2 and 3 into the DMX OUT of the last device. This reduces the risk of erratic behavior.
- Connect no more than 32 devices to one DMX line. For more devices or longer runs, use a DMX splitter or booster.

DMX line



Mode 1: every unit occupies 16 channels from its address. At most 32 units on one line; for more units or longer runs use a DMX splitter. A 120 Ω terminator closes the last DMX OUT.

7 Operation

Setting the DMX address


- The device occupies as many consecutive channels in the DMX universe as the selected DMX mode uses, starting at the set start address.
- Number of channels occupied in the DMX mode “Mode 1”: 16.
- Choose start addresses so that the channels of individual devices do not overlap and the last occupied channel does not exceed 512. Devices with the same start address and mode respond identically.
- For several devices in a row in the DMX mode “Mode 1”, you can use, for example, the start addresses 1, 17, 33, 49.
- The DMX mode set on the device must match the fixture profile (personality) used in the controller.

8 Functions at a glance

Functions in each DMX mode


	Mode 1 16 channels
Pan / Tilt	11, 13
Dimmer	1, 2
Shutter / strobe	3
Gobo wheel	4
Prism	5–8
Frost	9
Focus	10

Prism



9 DMX channels

Units in one DMX universe



Mode 1
16 channels

up to 32 units
last address 497

Start addresses of 20 units in the mode “Mode 1”


Unit	Start address	Unit	Start address	Unit	Start address	Unit	Start address
1	1	6	81	11	161	16	241
2	17	7	97	12	177	17	257
3	33	8	113	13	193	18	273
4	49	9	129	14	209	19	289
5	65	10	145	15	225	20	305

Mode 1

16-bit parameters use two channels, coarse and fine: value = 256 × coarse value + fine value.

If the device receives DMX in this mode but gives no light, check these channels: CH 3 Shutter at 104–107, 208–212 or 252–255 “Open”. The GDTF file gives these values for a console's Highlight function: CH 1 Colors 255, CH 2 Dimmer 255, CH 3 Shutter 255.

Channel functions at a glance



CH	Function	DMX	Description
1	Colors	0–4	Open
		5–9	White + Red
		10–14	Red
		15–19	Red + Orange
		20–24	Orange
		25–29	Orange + Aquamarine
		30–34	Aquamarine
		35–39	Aquamarine + Green
		40–44	Green
		45–49	Green + Light Green
		50–54	Light Green
		55–59	Light Green + Lavender
		60–64	Lavender
		65–69	Lavender + Pink
		70–74	Pink
		75–79	Pink + Yellow
		80–84	Yellow
		85–89	Yellow + Magenta
		90–94	Magenta
		95–99	Magenta + Cyan


CH	Function	DMX	Description
1	Colors (continued)	100–104	Cyan
		105–109	Cyan + CTO 260
		110–114	CTO 260
		115–119	CTO 260 + CTO 190
		120–124	CTO 190
		125–129	CTO 190 + CTB 8000
		130–134	CTB 8000
		135–139	CTB 8000 + White
		140–198	Fast Rotation
		199–200	Slow Rotation
		201–255	Fast Rotation
2	Dimmer	0–254	Min
		255	Max
3	Shutter	0–3	Closed
		4–102	Slow Strobe
		103	Fast Strobe
		104–107	Open
		108–206	Slow Pulse
		207	Fast Pulse
		208–212	Open
		213–225	Random Slow Strobe
		226–238	Random Medium Strobe
		239–251	Random Fast Strobe
		252–255	Open
4	Gobo Spin	0–4	Open
		5–9	Gobo1
		10–14	Gobo2
		15–19	Gobo3
		20–24	Gobo4
		25–29	Gobo5
		30–34	Gobo6
		35–39	Gobo7
		40–44	Gobo8
		45–49	Gobo9
		50–54	Gobo10
		55–59	Gobo11
		60–64	Gobo12
		65–69	Gobo13
		70–73	White Shake + Slow SPD
		74	White Shake + Fast SPD
		75–78	GB 1 + Slow SPD
		79	GB 1 + Fast SPD

CH	Function	DMX	Description
4	Gobo Spin (continued)	80–83	GB 2 + Slow SPD
		84–129	GB 2 + Fast SPD
		130–133	GB 12 Shake + Fast SPD
		134	GB 12 Shake + Fast SPD ... GB 13 Shake + Slow SPD
		135–138	GB 13 Shake + Slow SPD
		139	GB 13 Shake + Fast SPD
		140–199	Fast Rotation
		200–254	Slow Rotation
		255	Fast Rotation
5	Prism Rotation	0–127	No Prism
		128–255	Prism on
6	Prism Rotation Speed	0–127	Position
		128–190	Clockwise Rotation
		191–192	Stop
		193–255	Anti clockwise Rotation
7	Prism 2 Rotation	0–127	No Prism
		128–255	Prism on
8	Prism 2 Rotation Speed	0–127	Position
		128–190	Clockwise Rotation
		191–192	Stop
		193–255	Anti clockwise Rotation
9	Frost	0–127	No Frost
		128–255	Frost
10	Focus	0–255	Focus
11	Pan	0–127	Pan 1
		128	Home
		128–255	Pan 1
12	Pan Fine	0–255	Fine adjustment of CH 11
13	Tilt	0–127	Tilt 1
		128	Home
		128–255	Tilt 1
14	Tilt Fine	0–255	Fine adjustment of CH 13
15	Reset	0–255	
16	Lamp Control	0–99	No function
		100–105	Lamp off
		106–199	Lamp off ... Lamp on
		200–205	Lamp on
		206–249	Lamp on ... Complete Reset
		250–255	Complete Reset

10 Technical specifications

Parameter	Value
Light	
Light source	LED
LED power	700 W
Luminous flux	1,000 lm
Color temperature	6,000 K
Color rendering index (CRI)	85
Optics	
Beam angle	25°
Movement	
Pan	1,080°
Tilt	540°
Control	
DMX connection	3-pin XLR IN/OUT
Electrical	
Power supply	100–240 V, 50/60 Hz
Power consumption	850 W
Power connectors	PowerConBlue IN, NAC3FCB OUT
Dimensions and construction	
Weight	20 kg
Operating environment	
Operating temperature	0 to 40 °C

Spot diameter



Distance	Ø 25°
2 m	0.89 m
4 m	1.8 m
6 m	2.7 m
8 m	3.5 m
10 m	4.4 m
15 m	6.7 m

Spot diameter square to the beam axis, calculated from the beam angle.

11 Maintenance and cleaning

- Before cleaning and maintenance, switch the device off, disconnect it from the power supply and let it cool down.
- Clean the housing with a soft, dry or slightly damp cloth. Do not use solvents, abrasive cleaners or

pressure washers, and make sure no liquid gets into the device.

- Clean optical parts (lenses, front glass), if the device has any, with a soft lint-free cloth and a cleaner intended for optics or glass.
- Regularly inspect the housing, cables, connectors and fixings. Have damaged parts replaced by a service center.
- How often to clean depends on the environment; dust, smoke and fog make the device dirty much faster.

12 Troubleshooting

Problem	Remedy
The device does not switch on	Check the supply voltage, the cables and the fuse, if the device has one.
The device does not respond to DMX	Check the start address, the selected DMX mode and whether it matches the profile in the controller, the cable connection to DMX IN, and the controller output (universe).
The device behaves erratically or flickers	Check the terminator at the end of the line, the condition and wiring of the cables (shield on pin 1 only), the number of devices on the line (32 at most), and that the line is not split without a splitter.
Only some devices on the line respond	Check the cable and connectors between the last working and the first non-working device, and make sure all devices on the line are switched on.
Devices respond to the wrong channels or affect each other	Check that the addresses do not overlap and that the DMX mode on the devices matches the patch in the controller.
The device or the connected load does not light up although it receives DMX	Check the values of the dimmer, shutter and strobe channels against the DMX channel table. For the DMX modes for which the sources state it, the chapter DMX channels gives under the mode's heading which channels must be open.
Movement is reversed	Check whether Pan/Tilt inversion is enabled in the device menu or in the controller.
Moving parts do not reach the correct position after power-on or transport	Switch the device off and on again to reset the position, and make sure the transport lock, if any, is released. If this does not help, contact a service center.
Movement is jerky	Check the value of the Pan/Tilt speed channel, if the device has one, and the stability of the DMX signal.

13 Disposal

The crossed-out wheeled bin symbol on the product, in the manual or on the packaging means that the product must not be disposed of with unsorted household waste at the end of its life.

Take the end-of-life equipment to a collection point, for example a municipal collection site or a retailer. Proper disposal enables materials to be recycled and helps prevent possible negative effects on the environment and human health.

Follow the regulations applicable in your country; in the Czech Republic, take-back is governed by Act No. 542/2020 Coll., on End-of-Life Products.

Recycle the packaging materials according to their type.